

ISO/IEC TR 14165-312:2009-07 (E)

Information technology – Fibre channel – Part 312:
Avionics environment upper layer protocol (FC-AE 1553)

CONTENTS

FOREWORD.....	5
INTRODUCTION.....	7
1 Scope.....	8
2 Normative references	8
3 Terms, definitions and conventions.....	8
3.1 General considerations.....	8
3.2 Terms and definitions	9
3.3 Conventions	10
3.3.1 General	10
3.3.2 Binary notation	11
3.3.3 Hexadecimal notation	11
3.3.4 Abbreviations and acronyms.....	11
3.4 Applicability and use of this document.....	11
4 FC-AE-1553 profile.....	12
4.1 General	12
4.2 FC-AE-1553 elements	12
4.3 Mapping legacy 1553 applications to FC-AE-1553	13
4.3.1 General	13
4.3.2 NT address.....	14
4.3.3 NT subaddress	14
4.3.4 Byte Count/Mode code	15
4.4 FC-AE-1553 ULP features	15
4.4.1 Information units.....	15
4.4.2 Exchange formats.....	20
4.4.3 FC-AE-1553 ULP profile	40
4.4.4 MIL-STD-1553 ULP mapping to FC-AE-1553	44
Annex A (normative) FC-AE-1553 process login	72
A.1 Overview of process login and process logout	72
A.2 PRLI.....	73
A.2.1 Use of PRLI by FC-AE-1553.....	73
A.2.2 Process_Associator requirements	73
A.2.3 New or repeated process login	73
A.2.4 PRLI payload page length and payload length fields.....	73
A.2.5 PRLI request FC-AE-1553 service parameter page format.....	74
A.2.6 Operation of PRLI service parameters which are common to NC and NT.....	78
A.3 A.3 PRLO	79
Annex B (informative) FC-AE-1553 Fibre Channel profile.....	80
B.1 General	80
B.2 FC-FS-2 and FC-AL-2 features for FC-AE-1553.....	80
B.3 Point-to-point and link protocols	83
B.4 Arbitrated loop-specific features	83
B.5 Fabric login	84
B.5.1 Introduction	84

B.5.2 Fabric login – Common service parameters	84
B.5.3 Fabric login – Class specific service parameters	85
B.6 Port login.....	85
B.6.1 General	85
B.6.2 Classes of service supported.....	85
B.6.3 N_Port Login – Common service parameters.....	85
B.6.4 N_Port login – Class 3 service parameters	86
B.7 Basic link services	86
B.8 Broadcast and multicast support.....	86
B.9 FC-FS header fields	86
B.9.1 R_CTL field	86
B.9.2 TYPE field	86
B.9.3 Optional headers	86
B.9.4 Frame control (F_CTL)	86
B.9.5 Sequence identifier (SEQ_ID).....	87
B.9.6 Data field control (DF_CTL).....	87
B.9.7 Sequence count (SEQ_CNT).....	87
B.9.8 Originator exchange identifier (OX_ID).....	87
B.9.9 Responder exchange identifier (RX_ID).....	87
B.10 Extended link services.....	87
B.11 Well known address support.....	88
Annex C (informative) Bridging from FC-AE-1553 networks to MIL-STD-1553 buses.....	89
Bibliography.....	91

Figure 1 – Network Controller To Network Terminal transfers: NT Burst Size Request = '0'b, Delayed NT Burst Size Request = '0'b.....	21
Figure 2 – Network Controller To Network Terminal Transfers: NT Burst Size Request = '1'b, Delayed NT Burst Size Request = '0'b.....	22
Figure 3 – Network Controller to Network Terminal transfers: NT Burst Size Request = '0'b, Delayed NT Burst Size Request = '1'b.....	23
Figure 4 – Network Terminal-to-Network Controller.....	25
Figure 5 – NT-to-NT Transfers: NT Burst Size Request = '0'b, Delayed <i>NT Burst Size Request</i> = '0'b	26
Figure 6 – NT-to-NT transfers: NT Burst Size Request = '1'b, Delayed NT Burst Size Request = '0'b	28
Figure 7 – NT-to-NT Transfers: Originating NC is also receiving NT, with NT Burst Size Request = '1'b, Delayed NT Burst Size Request = '0'b	29
Figure 8 – NT-to-NT transfers: Delayed NT Burst Size Request = '1'b, NT Burst Size Request = '0'b	31
Figure 9 – NT-to-NT transfers: originating NC is also receiving NT, with delayed NT Burst Size Request = '1'b, NT Burst Size Request = '0'b.....	33
Figure 10 – Mode command without Data Word	35
Figure 11 – Transmit Mode Command with Data Word.....	35
Figure 12 – Receive Mode command with Data Word	36
Figure 13 – NC-to-NTs transfers (broadcast or multicast)	36
Figure 14 – Network Terminal to Multiple Network Terminals	38
Figure 15 – Transmit mode command without Data Word to Multiple Network Terminals.....	39

Figure 16 – Receive mode command with Data Word to Multiple Network Terminals	40
Figure 17 – FC-AE-1553 ULP timers: (a) NT_C/S_TOV and NT_C-D/S_BURST_TOV; (b) NC_C/S_TOV and NC_C-D/S_BURST_TOV; (c) C-S/D_TX_TOV (shown for NC and NT); (d) C-S/D_RX_TOV (shown for NC and NT)	62
Figure C.1 – FC-AE-1553 network to MIL-STD-1553 bus bridge.....	89
Table 1 – Summary and use of features.....	12
Table 2 – Terminology equivalents between MIL-STD-1553 and FC-AE-1553	13
Table 3 – Comparison of MIL-STD-1553 and FC-AE-1553 Command Field Sizes.....	14
Table 4 – Information units transmitted by the Network Controller to Network Terminal, and transmissions by the transmitting NT for NT-to-NT or NT-to-NTs transfers	16
Table 5 – Information Units Initiated from the Network Terminal, Excluding Transmissions by the Transmitting NT for NT-to-NT or NT-to-NTs Transfers.....	19
Table 6 – FC-4 profile for FC-AE-1553.....	41
Table 7 – FC-AE-1553 command sequence header	46
Table 8 – Multicast address or other Port_ID Field.....	52
Table 9 – FC-AE-1553 status sequence header	57
Table 10 – Correct values for F_CTL field bits	64
Table 11 – Values for D_ID field (for broadcast); NT-to-NT Transfer, T/R*, Tx RDMA, and RDMA bits; subaddress, byte Count/Mode code, and other subaddress fields.....	65
Table 12 – Correct values for fourth word of FC-AE-1553 header extension.....	69
Table 13 – Correct Values for multicast address or other Port_ID field.....	69
Table A.1 – FC-AE-1553 PRLI service parameter page, PRLI request and accept	74
Table A.2 – FC-AE-1553 PRLI service parameters – corresponding words/bits for PRLI parameters which are common to NC and NT operation.....	79
Table B.1 – FC-FS and FC-AL-2 Features for FC-AE-1553	80
Table C.1 – Use of FC-AE-1553 subaddress and/or other subaddress field for command sequences involving bridging to MIL-STD-1553 RTs	89