

# ISO 9869-1:2014-08 (E)

## Thermal insulation - Building elements - In-situ measurement of thermal resistance and thermal transmittance - Part 1: Heat flow meter method

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions, symbols and units .....</b>	<b>2</b>
<b>3.1</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>3.2</b>	<b>Symbols and units .....</b>	<b>2</b>
<b>4</b>	<b>Apparatus .....</b>	<b>4</b>
<b>4.1</b>	<b>Heat flow meter (HFM) .....</b>	<b>4</b>
<b>4.2</b>	<b>Temperature sensors .....</b>	<b>4</b>
<b>5</b>	<b>Calibration procedure .....</b>	<b>5</b>
<b>5.1</b>	<b>Calibration of the HFM .....</b>	<b>5</b>
<b>5.2</b>	<b>Temperature sensors .....</b>	<b>6</b>
<b>5.3</b>	<b>Measuring equipment .....</b>	<b>7</b>
<b>6</b>	<b>Measurements .....</b>	<b>7</b>
<b>6.1</b>	<b>Installation of the apparatus .....</b>	<b>7</b>
<b>6.2</b>	<b>Data acquisition .....</b>	<b>8</b>
<b>7</b>	<b>Analysis of the data .....</b>	<b>8</b>
<b>7.1</b>	<b>Average method .....</b>	<b>8</b>
<b>7.2</b>	<b>Storage effects .....</b>	<b>10</b>
<b>7.3</b>	<b>Comparison of calculated and measured values .....</b>	<b>12</b>
<b>8</b>	<b>Corrections for the thermal resistance and the finite dimension of the HFM .....</b>	<b>12</b>
<b>9</b>	<b>Accuracy .....</b>	<b>12</b>
<b>10</b>	<b>Test report .....</b>	<b>13</b>
	<b>Annex A (normative) Heat transfer at surfaces and U-value measurement .....</b>	<b>15</b>
	<b>Annex B (normative) Dynamic analysis method .....</b>	<b>18</b>
	<b>Annex C (normative) Examination of the structure of the element .....</b>	<b>23</b>
	<b>Annex D (informative) Perturbations caused by the heat flow meter .....</b>	<b>25</b>
	<b>Annex E (informative) Checking the accuracy of the measurement system of heat flow rate .....</b>	<b>31</b>
	<b>Annex F (informative) Heat storage effects .....</b>	<b>34</b>
	<b>Bibliography .....</b>	<b>36</b>