

# ISO 4343:2000-10 (E)

## Industrial automation systems - Numerical control of machines - NC processor output; Post processor commands

---

<b>Contents</b>		<b>Page</b>
Foreword .....		viii
Introduction .....		ix
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Co-ordinate system .....</b>	<b>1</b>
3.1	Part program reference .....	1
3.2	Machine program reference .....	1
3.3	Units of measure .....	2
<b>4</b>	<b>General structure of post processor commands .....</b>	<b>2</b>
4.1	NC processor .....	2
4.2	CLDATA .....	2
4.3	Post processor .....	3
<b>5</b>	<b>General language .....</b>	<b>6</b>
5.1	General comments .....	6
5.2	The ADAPTV command .....	8
5.3	The AIR command .....	9
5.4	The APPLY command .....	10
5.5	The AUXFUN command .....	11
5.6	The BREAK command .....	12
5.7	The CALSUB command .....	13
5.8	The CLAMP command .....	14
5.9	The CLDATA command .....	15
5.10	The COUPLE command .....	16
5.11	The CUTCOM command .....	17
5.12	The DEFSUB command .....	18
5.13	The DELAY command .....	19
5.14	The DISPLY command .....	20
5.15	The END command .....	21
5.16	The ENDSUB command .....	22
5.17	The FEDRAT command .....	23
5.18	The GOHOME command .....	26
5.19	The GOPARK command .....	27
5.20	The HOMEPT command .....	28
5.21	The INCLUD command .....	29
5.22	The INSERT command .....	30
5.23	The LEADER command .....	31
5.24	The LIMIT command .....	32
5.25	The LOCATE command .....	33
5.26	The LPRINT command .....	34
5.27	The MACHIN command .....	35
5.28	The MATERL command .....	36
5.29	The MCHFIN command .....	37
5.30	The MCHTOL command .....	38
5.31	The MODE command .....	39
5.32	The MOVETO command .....	43

5.33	The OPSKIP command .....	44
5.34	The OPSTOP command .....	45
5.35	The ORIGIN command .....	46
5.36	The PARKPT command .....	47
5.37	The PARTNO command .....	48
5.38	The PPFUN command .....	49
5.39	The PPRINT command .....	50
5.40	The PPTIME command .....	51
5.41	The PREFUN command .....	52
5.42	The RAPID command .....	53
5.43	The RESET command .....	54
5.44	The REWIND command .....	55
5.45	The SAFPOS command .....	56
5.46	The SEQNO command .....	57
5.47	The STOP command .....	58
5.48	The SYNCTR command .....	59
5.49	The TLLIFE command .....	61
5.50	The TMARK command .....	62
5.51	The TRANS command .....	63
6	Die sinking EDM language .....	64
6.1	General comments .....	64
6.2	The APPLY command .....	65
6.3	The CUTCOM command .....	66
6.4	The FLUSH command .....	69
6.5	The GENRTR command .....	72
6.6	The LOAD command .....	73
6.7	The OP command .....	74
6.8	The SELECT command .....	78
6.9	The SPINDL command .....	79
6.10	The TOOLNO command .....	83
6.11	The UNLOAD command .....	84
7	Flame cutting language .....	85
7.1	General comments .....	85
7.2	The APPLY command .....	86
7.3	The ASSIST command .....	87
7.4	The CLDIST command .....	88
7.5	The PIERCE command .....	89
7.6	The TORCH command .....	90
8	Grinding language .....	91
8.1	General comments .....	91
8.2	The APPLY command .....	92
8.3	The DRESS command .....	93
9	Laser-beam machining language .....	94
9.1	General comments .....	94
9.2	The APPLY command .....	95
9.3	The ASSIST command .....	96
9.4	The CLDIST command .....	97
9.5	The CYCLE command .....	98
9.6	The PIERCE command .....	101
10	Milling and drilling language .....	102
10.1	General comments .....	102
10.2	The APPLY command .....	103
10.3	The ARCSLP command .....	104
10.4	The CLAMP command .....	105
10.5	The CLEARP command .....	106
10.6	The COOLNT command .....	107
10.7	The CUTCOM command .....	108

10.8	The CYCLE command .....	111
10.9	The HEAD command .....	133
10.10	The INDPOS command .....	134
10.11	The LINTOL command .....	135
10.12	The LOAD command .....	136
10.13	The ORIGIN command .....	137
10.14	The RETRACT command .....	140
10.15	The ROTATE command .....	141
10.16	The SELECT command .....	142
10.17	The SPINDL command .....	143
10.18	The TOOLNO command .....	147
10.19	The UNLOAD command .....	148
11	Punching and forming language .....	149
11.1	General comments .....	149
11.2	The APPLY command .....	150
11.3	The CLAMP command .....	151
11.4	The CYCLE command .....	152
11.5	The LOAD command .....	163
11.6	The PIERCE command .....	164
11.7	The SELECT command .....	165
11.8	The TOOLNO command .....	166
11.9	The UNLOAD command .....	168
12	Turning language .....	169
12.1	General comments .....	169
12.2	The APPLY command .....	171
12.3	The BARFED command .....	172
12.4	The CATCHR command .....	173
12.5	The CHUCK command .....	174
12.6	The CLAMP command .....	176
12.7	The COOLNT command .....	179
12.8	The COUPLE command .....	180
12.9	The CUTCOM command .....	181
12.10	The DEFCON command .....	182
12.11	The LOAD command .....	183
12.12	The MODE command .....	184
12.13	The OP command .....	185
12.14	The PITCH command .....	195
12.15	The SAFETY command .....	196
12.16	The SELECT command .....	197
12.17	The SPINDL command .....	198
12.18	The STAN command .....	202
12.19	The STDYRS command .....	203
12.20	The TLSTCK command .....	204
12.21	The TOOLNO command .....	205
12.22	The TURRET command .....	206
12.23	The UNLOAD command .....	207
13	Wire EDM language .....	208
13.1	General comments .....	208
13.2	The APPLY command .....	209
13.3	The CLDIST command .....	210
13.4	The CUTCOM command .....	211
13.5	The CYCLE command .....	212
13.6	The FLUSH command .....	215
13.7	The GENRTR command .....	218
13.8	The LOAD command .....	219
13.9	The ORIGIN command .....	220
13.10	The SELECT command .....	221
13.11	The STAN command .....	222
13.12	The TOOLNO command .....	223

13.13	The UNLOAD command .....	224
14	Probing language .....	225
14.1	General comments .....	225
14.2	The APPLY command .....	226
14.3	The LOAD command .....	227
14.4	The MODE command .....	228
14.5	The PROBE command .....	231
14.6	The SELECT command .....	237
14.7	The TOOLNO command .....	238
14.8	The UNLOAD command .....	239
14.9	The VERIFY command .....	240
15	Drafting and plotting language .....	250
15.1	General comments .....	250
15.2	The DRAFT command .....	251
15.3	The LETTER command .....	252
15.4	The OVPLOT command .....	253
15.5	The PENDWN command .....	254
15.6	The PENUP command .....	255
15.7	The PLOT command .....	256
	Annex A (normative) Rules used in the syntax definitions .....	258
	Annex B (normative) List of keywords .....	259