DIN EN 14825:2016-10 (E)

Air conditioners, liquid chilling pack ages and heat pumps, with electrically driven compressors, for space heating and cooling - Testing and rating at part load conditions and calculation of seasonal performance

Contents

Page

European foreword 5

Introduction 8

1 Scope 9

2 Normative references 9

3 Terms, definitions, symbols, abbreviated terms and units 9
3.1 Terms and definitions 9
3.2 Symbols, abbreviated terms and units 21

4 Part load conditions in cooling mode 23
4.1 General 23
4.2 Air-to-air units 23
4.3 Water-to-air units and brine-to-air units 24
4.4 Air-to-water units 24
4.5 Water-to-water and brine-to-water units 25

5 Part load conditions in heating mode 26
5.1 General 26
5.2 Air-to-air units 27
5.3 Water-to-air and brine-to-air units 28
5.4 Air-to-water units 28
5.4.1 General 28
5.4.2 Low temperature application 29
5.4.3 Intermediate temperature application 30
5.4.4 Medium temperature application 31
5.4.5 High temperature application 32
5.5 Water-to-water and brine-to-water units 32
5.5.1 General 32
5.5.2 Low temperature application 33
5.5.3 Intermediate temperature application 34
5.5.4 Medium temperature application 35
5.5.5 High temperature application 36

6 Calculation methods for SEER and SEERon 36
6.1 General formula for calculation of SEER 36
6.2 Calculation of the reference annual cooling demand QC 37
6.3 Calculation of the reference annual electricity consumption QCE 37
6.4 Calculation of SEERon 37
6.5 Calculation procedure for determination of EERbin values at part load conditions B, C, D 38
6.5.1 General 38
6.5.2 Calculation procedure for fixed capacity units 38
6.5.3 Calculation procedure for staged and variable capacity units 39

7 Calculation methods for seasonal space heating efficiency s, SCOP, SCOPon and SCOPnet 40

7.1 Calculation of the seasonal space heating efficiency s ... 40
7.2 General formula for calculation of SCOP ... 40
7.3 Calculation of the reference annual heating demand QH ... 41
7.4 Calculation of the annual electricity consumption QHE ... 41
7.5 Calculation of SCOPon and SCOPnet ... 41
7.6 Calculation procedure for determination of COPbin values at part load conditions A to G 43
7.6.1 General ... 43
7.6.2 Air-to-air, brine-to-air and water-to-air units ... 43
7.6.3 Air-to-water, water-to-water and brine-to-water units ... 44

8 Test methods for testing capacities, EERbin and COPbin values during active mode at part load conditions ... 45
8.1 General ... 45
8.2 Basic principles ... 45
8.3 Uncertainties of measurement ... 46
8.4 Test procedures for units with fixed capacity ... 47
8.4.1 General ... 47
8.4.2 Air-to-air and water-to-air units - Determination of the degradation coefficients Cdc and Cdh ... 47
8.4.3 Air-to-water units and water-to-water units - Determination of the degradation factors Cdc and Cdh ... 49
8.5 Test procedure for staged and variable capacity units ... 49
8.5.1 Settings for the required capacity ratio ... 49
8.5.2 Compensation method ... 49

9 Test methods for electric power input during thermostat-off mode, standby mode and crankcase heater mode and off mode ... 50
9.1 Measurement of electric power consumption during thermostat-off mode ... 50
9.2 Measurement of the electric power consumption during standby mode ... 50
9.3 Measurement of the electric power consumption during crankcase heater mode ... 51
9.4 Measurement of the electric power consumption during off mode ... 51

10 Test report ... 51

11 Technical data sheet ... 51

Annex A (normative) Applicable climate bin hours and hours for active mode, thermostat- off, standby, off mode and crankcase heater mode for air conditioners below and equal to 12 kW ... 53

A.1 Climate bins ... 53
A.1.1 Bin limit temperature ... 53
A.1.2 Cooling ... 53
A.1.3 Heating ... 53
A.2 Hours for active mode, thermostat-off, standby, off mode ... 55
A.2.1 Cooling ... 55
A.2.2 Heating ... 55
A.3 Hours used for crankcase heater mode ... 55
A.3.1 Cooling ... 55
A.3.2 Heating ... 55

Annex B (normative) Applicable climate bin hours and hours for active, thermostat-off, standby, off and crankcase heater modes for space heaters, air to water and water/brine to water units, below or equal to 400kW ... 56

B.1 Climate bins ... 56
B.1.1 Bin limit temperature ... 56
B.1.2 Heating ... 56
B.2 Hours for active, thermostat off, standby and off modes - Heating ... 57
B.3 Hours used for crankcase heater mode - Heating ... 57

Annex C (normative) Template for technical data sheet ... 58

C.1 For air to air units below and equal to 12 kW 58
C.2 For space heaters, air-to-water and water/brine-to-water units below or equal to 400kW ...61

Annex D (informative) Adaption of water temperature for fixed capacity units 63

Annex E (informative) Calculation example for SEERon and SEER - Application to a reversible air-to-air unit with variable capacity 66

E.1 Calculation of SEERon 66
E.2 Calculation of SEER 68
E.2.1 Calculation of reference annual cooling demand (QC) according to Formula (2) 68
E.2.2 Calculation of SEER according to Formula (1) 68

Annex F (informative) Calculation example for SCOPon and SCOPnet - Application to a fixed capacity air-to-water heat pump used for floor heating 69

Annex G (informative) Calculation example for SCOPon and SCOPnet - Application to a fixed capacity brine-to-water heat pump used for medium temperature application 73

Annex H (informative) Compensation methods for air-to-water and water/brine-to-water units 78

H.1 General 78
H.2 Compensation system for reduced capacity test in cooling mode 78
H.3 Compensation system for reduced capacity test in heating mode 78

Annex ZA (informative) Relationship between this European Standard and the requirements of Commission Regulation (EU) No 206/2012 80

Annex ZB (informative) Relationship between this European Standard and the requirements of Commission Regulation (EU) No 813/2013 and Commission Delegated Regulation (EU) No 811/2013 82

Bibliography 85