DIN EN 16334:2014-12 (E)

Railway applications - Passenger Alarm System - System requirements

Contents

Page

Foreword 4

1 Scope 5

2 Normative references 5

3 Terms and definitions 6

4 Symbols and abbreviated terms 7

5 System overview, architecture and interfaces 7

6 Functional requirements 7
6.1 General 7
6.2 Advise the driver (and optionally on board staff members or control centre) of a potential danger 7
6.3 Advise the passenger 8
6.4 Manage PAS communication 9
6.5 Determine if the train is stopped at a platform or departing from a platform 10
6.6 Recognize the action of the driver 10
6.7 Request brake action 10
6.8 PAS actions after PAD activation 11
6.9 PAS power up in the active cab or train reconfiguration 11
6.10 Driver acknowledgement 11
6.11 Overriding PAS brake request 12
6.12 Reset the PAS 12

7 Event sequence 12

8 Degraded modes 12
8.1 PAS degraded mode: isolated or not functioning 12
8.2 Advising the driver 12

9 Minimum safety requirements 13

10 Requirements for PAD 13
10.1 Installation requirements 13
10.2 Passenger interface 14
10.2.1 PAD 14
10.2.2 Information labels 15

Annex A (normative) PAS information management 17

Annex B (normative) PAS brake request management 19

Annex C (normative) Sign indicating the reset equipment for the local PAD 20

Annex D (informative) Square key to restore the passenger emergency brake PAD in the initial position (mandatory for international service trains) 22

Annex E (informative) System overview 23

Annex F (normative) Overall dimension of the PAD handle interface 25

Annex G (informative) Inscription indicating the PAD 26

Annex H (informative) Label for PAD 27

Annex I (informative) Degraded mode 29

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2008/57/EC 31

Bibliography 34