ISO 11783-7:2009-05 (E)

Tractors and machinery for agriculture and forestry - Serial control and communications data network - Part 7: Im plement messages application layer

Contents

Page

Foreword ix

Introduction x

1 Scope 1

2 Normative references 1

3 General requirements and recommendations 2
3.1 General 2
3.2 Signal characterization 2
3.3 Message format 2
3.3.1 General 2
3.3.2 Data types 4
3.3.3 Parameter ranges 4
3.3.4 Adding to parameter groups 4
3.4 Implement configuration offsets 5

Annex A (normative) Parameter definitions 6

A.1 Time (UTC) 6
A.2 Date 6
A.3 Local minute offset 7
A.4 Local hour offset 7
A.5 Ground-based machine speed 8
A.6 Ground-based machine distance 8
A.7 Ground-based machine direction 8
A.8 Wheel-based machine speed 9
A.9 Wheel-based machine distance 9
A.10 Wheel-based machine direction 9
A.11 Key switch state 10
A.12 Maximum time of tractor power 10
A.13 Maintain ECU power 10
A.14 Maintain actuator power 11
A.15 Implement transport state 11
A.16 Implement park state 11
A.17 Implement work state 12
A.18 Navigation location parameters 12
A.19 Hitch parameters 12
A.19.1 Front hitch position 12
A.19.2 Rear hitch position 13
A.19.3 Front hitch position -- Command 13
A.19.4 Rear hitch position -- Command 13
A.19.5 Front hitch in-work indication 14
A.19.6 Rear hitch in-work indication 14
A.19.7 Front draft 14
A.19.8 Rear draft 15
A.19.9 Front nominal lower link force 15
A.19.10 Rear nominal lower link force 15
A.19.11 Front hitch position limit status 16
A.19.12 Rear hitch position limit status 16

A.20 PTO parameters 17
A.20.1 Front PTO output shaft speed 17
A.20.2 Rear PTO output shaft speed 17
A.20.3 Front PTO output shaft speed set point 18
A.20.4 Rear PTO output shaft speed set point 18
A.20.5 Front PTO output shaft speed set point -- Command 18
A.20.6 Rear PTO output shaft speed set point -- Command 18
A.20.7 Front PTO engagement 19
A.20.8 Rear PTO engagement 19
A.20.9 Front PTO mode 19
A.20.10 Rear PTO mode 20
A.20.11 Front PTO economy mode 20
A.20.12 Rear PTO economy mode 20
A.20.13 Front PTO engagement -- Command 21
A.20.14 Rear PTO engagement -- Command 21
A.20.15 Front PTO mode -- Command 21
A.20.16 Rear PTO mode -- Command 22
A.20.17 Front PTO economy mode -- Command 22
A.20.18 Rear PTO economy mode -- Command 22
A.20.19 Front PTO engagement request status 23
A.20.20 Front PTO mode request status 23
A.20.21 Front PTO economy mode request status 23
A.20.22 Front PTO shaft speed limit status 24
A.20.23 Rear PTO engagement request status 24
A.20.24 Rear PTO mode request status 25
A.20.25 Rear PTO economy mode request status 25
A.20.26 Rear PTO shaft speed limit status 25
A.21 Auxiliary valve parameters 26
A.21.1 Auxiliary valve number 26
A.21.2 Auxiliary valve number 0 extend port measured flow 26
A.21.3 Auxiliary valve number 0 retract port measured flow 27
A.21.4 Auxiliary valve number 0 extend port estimated flow 27
A.21.5 Auxiliary valve number 0 retract port estimated flow 27
A.21.6 Auxiliary valve number 0 valve state 28
A.21.7 Auxiliary valve number 0 extend port pressure 28
A.21.8 Auxiliary valve number 0 retract port pressure 28
A.21.9 Auxiliary valve number 0 return port pressure 29
A.21.10 Auxiliary valve number 0 port flow -- Command 29
A.21.11 Auxiliary valve number 0 state -- Command 29
A.21.12 Auxiliary valve number 0 fail safe mode -- Command 30
A.21.13 Auxiliary valve number 0 fail safe mode 30
A.21.14 Auxiliary valve number 0 measured flow limit status 30
A.21.15 Auxiliary valve number 0 estimated flow limit status 31
A.21.16 Parameters for auxiliary valves numbers 1 to 14 31
A.21.17 Auxiliary valve number 15 extend port measured flow 32
A.21.18 Auxiliary valve number 15 retract port measured flow 32
A.21.19 Auxiliary valve number 15 extend port estimated flow 32
A.21.20 Auxiliary valve number 15 retract port estimated flow 33
A.21.21 Auxiliary valve number 15 valve state 33
A.21.22 Auxiliary valve number 15 extend port pressure 33
A.21.23 Auxiliary valve number 15 retract port pressure 34
A.21.24 Auxiliary valve number 15 return port pressure 34
A.21.25 Auxiliary valve number 15 port flow -- Command 34
A.21.26 Auxiliary valve number 15 state -- Command 35
A.21.27 Auxiliary valve number 15 fail safe mode -- Command 35
A.21.28 Auxiliary valve number 15 fail safe mode 35
A.21.29 Auxiliary valve number 15 measured flow limit status 36
A.21.30 Auxiliary valve number 15 estimated flow limit status 36
A.21.31 General-purpose valve extend port measured flow 37
A.21.32 General-purpose valve retract port measured flow 37
A.21.33 General-purpose valve extend port estimated flow 37
A.21.34 General-purpose valve retract port estimated flow 38

A.21.35 General-purpose valve state 38
A.21.36 General-purpose valve extend port pressure 39
A.21.37 General-purpose valve retract port pressure 39
A.21.38 General-purpose valve return port pressure 39
A.21.39 General-purpose valve port flow -- Command 39
A.21.40 General-purpose valve state -- Command 40
A.21.41 General-purpose valve fail safe mode -- Command 40
A.21.42 General-purpose valve fail safe mode 40
A.21.43 General-purpose valve load sense pressure 41
A.21.44 General-purpose valve pilot pressure 41
A.21.45 General-purpose valve assembly load sense pressure 41
A.21.46 General-purpose valve assembly supply pressure 41
A.21.47 General-purpose valve measured limit status 42
A.21.48 General-purpose valve estimated limit status 42
A.22 Lighting parameters 43
A.22.1 High-beam headlights -- Command 43
A.22.2 High-beam headlights 43
A.22.3 Low-beam headlights -- Command 44
A.22.4 Low-beam headlights 44
A.22.5 Alternate headlights -- Command 44
A.22.6 Alternate headlights 45
A.22.7 Tractor front low-mounted work lights -- Command 45
A.22.8 Tractor front low-mounted work lights 45
A.22.9 Tractor front high-mounted work lights -- Command 46
A.22.10 Tractor front high-mounted work lights 46
A.22.11 Tractor underside-mounted work lights -- Command 46
A.22.12 Tractor underside-mounted work lights 47
A.22.13 Tractor rear low-mounted work lights -- Command 47
A.22.14 Tractor rear low-mounted work lights 47
A.22.15 Tractor rear high-mounted work lights -- Command 48
A.22.16 Tractor rear high-mounted work lights 48
A.22.17 Tractor side low-mounted work lights -- Command 48
A.22.18 Tractor side low-mounted work lights 49
A.22.19 Tractor side high-mounted work lights -- Command 49
A.22.20 Tractor side high-mounted work lights 49
A.22.21 Left-turn signal lights -- Command 50
A.22.22 Left-turn signal lights 50
A.22.23 Right-turn signal lights -- Command 50
A.22.24 Right-turn signal lights 51
A.22.25 Left stop lights -- Command 51
A.22.26 Left stop lights 51
A.22.27 Right stop lights -- Command 52
A.22.28 Right stop lights 52
A.22.29 Centre stop lights -- Command 52
A.22.30 Centre stop lights 53
A.22.31 Tractor marker (position) lights -- Command 53
A.22.32 Tractor marker (position) lights 53
A.22.33 Implement marker (position) lights -- Command 54
A.22.34 Implement marker (position) lights 54
A.22.35 Tractor clearance lights -- Command 54
A.22.36 Tractor clearance lights 55
A.22.37 Implement clearance lights -- Command 55
A.22.38 Implement clearance lights 55
A.22.39 Rotating beacon light -- Command 56
A.22.40 Rotating beacon light 56
A.22.41 Tractor front fog lights -- Command 56
A.22.42 Tractor front fog lights 57
A.22.43 Rear fog lights -- Command 57
A.22.44 Rear fog lights 57
A.22.45 Implement rear work lights -- Command 58
A.22.46 Implement rear work lights 58
A.22.47 Implement OEM option 1 light -- Command 58

A.22.48 Implement OEM option 1 light ... 59
A.22.49 Implement OEM option 2 light -- Command ... 59
A.22.50 Implement OEM option 2 light ... 59
A.22.51 Back-up lights and alarm horn -- Command ... 60
A.22.52 Back-up lights and alarm horn ... 60
A.22.53 Implement left forward work lights -- Command ... 60
A.22.54 Implement left forward work lights ... 61
A.22.55 Implement right forward work lights -- Command ... 61
A.22.56 Implement right forward work lights ... 61
A.22.57 Implement left-facing work lights -- Command ... 62
A.22.58 Implement left-facing work lights ... 62
A.22.59 Implement right-facing work lights -- Command ... 62
A.22.60 Implement right-facing work lights ... 63
A.22.61 Daytime running lights -- Command ... 63
A.22.62 Daytime running lights ... 63
A.22.63 Lighting data message request -- Command ... 64
A.22.64 Background illumination level -- Command ... 64
A.23 Language-specific parameters ... 64
A.23.1 Language code ... 64
A.23.2 Decimal symbol ... 65
A.23.3 Date format ... 65
A.23.4 Time format ... 65
A.23.5 Units of measure parameters ... 66
A.23.6 Repetition rate -- Command ... 68
A.23.7 Repetition rate ... 69
A.24 Working set parameters ... 69
A.24.1 Number of members in working set ... 69
A.24.2 NAME of working set member ... 69
A.25 Implement operating state parameters ... 70
A.25.1 Implement operating state -- Command ... 70
A.25.2 Implement Start/Stop operations ... 70
A.25.3 Stop all implement operations ... 70
A.26 Tractor control parameters ... 71
A.26.1 General ... 71
A.26.2 Tractor control mode commands ... 71
A.26.3 Tractor control command value parameters ... 74
A.26.4 Tractor control mode command response parameters ... 78
A.26.5 Tractor control value response parameters ... 81
A.26.6 Tractor control limit parameters ... 84
A.26.7 Tractor control limit status ... 86
A.26.8 Tractor control limit command parameters ... 86
A.27 Tractor facility parameters ... 88
A.27.1 General ... 88
A.27.2 Tractor ECU class request ... 88
A.27.3 Tractor facility request ... 88
A.27.4 Tractor ECU class response ... 88
A.27.5 Tractor facility response ... 89
A.27.6 Tractor facility reserved bit indicator ... 89
A.28 Guidance commands ... 89
A.28.1 Curvature command ... 89
A.28.2 Estimated curvature ... 90
A.28.3 Curvature command status ... 90
A.28.4 Request reset command status ... 90
A.28.5 Steering input position status ... 91
A.28.6 Steering system readiness ... 91
A.28.7 Mechanical system lockout ... 91
A.29 ISOBUS compliance certification parameters ... 92
A.29.1 ISOBUS compliance certification year ... 92
A.29.2 ISOBUS compliance certification revision ... 92
A.29.3 ISOBUS compliance certification laboratory type ... 93
A.29.4 Compliance certification laboratory ID ... 93
A.29.5 Compliance certification type -- Minimum ECU ... 93

A.29.6 Compliance certification type -- TECU Class 1 94
A.29.7 Compliance certification type -- TECU Class 2 94
A.29.8 Compliance certification type -- TECU Class 3 94
A.29.9 Compliance certification type -- Class 3 ECU 95
A.29.10 Compliance certification type -- Virtual terminal 95
A.29.11 Compliance certification type -- VT working set master 95
A.29.12 Compliance certification type -- VT working set member 96
A.29.13 Compliance certification type -- Task controller 96
A.29.14 Compliance certification type -- TC working set master 96
A.29.15 Compliance certification type -- TC working set member 97
A.29.16 Compliance certification type -- File server 97
A.29.17 Compliance certification type -- GPS receiver 97
A.29.18 Compliance certification reference number 98
A.30 Selected speed control parameters 98
A.30.1 Machine selected speed 98
A.30.2 Machine selected distance 98
A.30.3 Machine selected direction 99
A.30.4 Machine selected speed source 99
A.30.5 Machine selected speed set point command 100
A.30.6 Machine selected direction command 100
A.30.7 Machine selected speed set point limit 100
A.30.8 Machine selected speed limit status 101
A.31 Operator direction reversed 101

Annex B (normative) Parameter groups 102

B.1 Time/Date 102
B.2 Ground-based speed and distance 102
B.3 Wheel-based speed and distance 103
B.4 Maintain power 104
B.5 Navigation location system messages 104
B.6 Secondary or front hitch status 105
B.7 Primary or rear hitch status 105
B.8 Secondary or front PTO output shaft 106
B.9 Primary or rear PTO output shaft 107
B.10 Hitch and PTO commands 108
B.11 Auxiliary valve 0 estimated flow 109
B.12 Auxiliary valve 0 measured flow 110
B.13 Auxiliary valve 0 command 111
B.14 Auxiliary valve 1 to 14 messages 112
B.15 Auxiliary valve 15 estimated flow 114
B.16 Auxiliary valve 15 measured flow 115
B.17 Auxiliary valve 15 command 115
B.18 Lighting command 116
B.19 Lighting data 118
B.20 Background lighting level command 119
B.21 Language command 120
B.22 Flexible repetition rates 121
B.22.1 Request for repetition rate 121
B.22.2 Response for repetition rate 121
B.23 Working set master 122
B.23.1 General 122
B.23.2 Working set member 122
B.24 Tractor control messages 123
B.24.1 Tractor control mode command 123
B.24.2 Tractor control command tractor response 124
B.24.3 Tractor facility response message 124
B.24.4 Required tractor facilities message 127
B.25 General-purpose valve messages 129
B.25.1 General 129
B.25.2 General-purpose valve estimated flow 129
B.25.3 General-purpose valve measured flow 130

B.25.4 General-purpose valve command 130
B.25.5 General-purpose valve load sense pressure 131
B.26 Guidance system messages 131
B.26.1 Guidance system command 131
B.26.2 Guidance machine status 132
B.27 ISOBUS compliance certification message 132
B.28 Machine selected speed messages 134
B.28.1 Machine selected speed 134
B.28.2 Machine selected speed command 134
B.29 Implement operating state command 135
B.30 All implements stop operations switch state 135

Annex C (informative) Tractor control messages -- Examples 136

C.1 Initialization, error recovery and background 136
C.2 Cruise control 137
C.3 Combined constant PTO speed and cruise control 140
C.4 Auxiliary valve slip control with cruise control 142

Annex D (informative) Implement control of tractor facilities -- Control implementation 143

Bibliography 144