ISO 11525-2:2020-01 (E)

Rough-terrain trucks - Safe use requirements - Part 2: Slewing variable-reach trucks

Contents

Page

Foreword ..... **iv**

Introduction ..... **v**

1 Scope **1**

2 Normative references **1**

3 Terms and definitions **1**

4 General requirements **2**
- 4.1 Principles 2
- 4.2 Operator's manual(s) 2
- 4.3 Modifications or alterations 2
- 4.4 Manufacturer's bulletins 3
- 4.5 Operator qualifications and training 3
- 4.6 Inspection and maintenance 3
  - 4.6.1 General 3
  - 4.6.2 Preparation for inspection or repair 3
  - 4.6.3 Performance checks 4
  - 4.6.4 Inspection and maintenance precautions 5
  - 4.6.5 Inspection and maintenance requirements 5
- 4.7 Hazardous environments 6
- 4.8 Refuelling 6

5 Operating safety rules and precautions **6**
- 5.1 Operator's responsibility for safety 6
- 5.2 Visual inspection and functional tests 7
- 5.3 General operating instructions 8
- 5.4 Travelling 9
- 5.5 Picking and placing loads 10
- 5.6 Using attachments 11

Bibliography **13**