ISO 12510:2004-03 (E)

Earth-moving machinery - Operation and maintenance - Maintainability guidelines

Contents

Page

Foreword iv

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 General 1

5 Location of items 2

6 Access system 3

7 Access apertures 3

8 Covers 4

9 Tools 4

10 Service instrumentation 4

11 Labelling 4

12 Accompanying documentation 5

Annex A (informative) Matrixes of maintainability 7

Bibliography 11