DIN EN 14985:2012-05 (E)

Cranes - Slewing jib cranes

Contents

Page

Foreword 4

Introduction 5

1 Scope 6

2 Normative references 6

3 Terms and definitions 8

4 List of hazards 8

5 Safety requirements and/or protective measures 12
5.1 General 12
5.2 Requirements for strength and stability 12
5.2.1 Selection of classification parameters 12
5.2.2 Selection of loads and load combinations 12
5.2.3 Determination of factor 2 12
5.2.4 Stall load condition 13
5.2.5 Loads caused by acceleration 14
5.2.6 Jib side loading 14
5.2.7 Test loads 14
5.2.8 Conditions of use of permissible stress method and limit state method 14
5.2.9 Stability of rail mounted cranes 15
5.3 Electrotechnical equipment 16
5.3.1 General 16
5.3.2 Physical environment and operating conditions 16
5.3.3 Electrical supply 16
5.3.4 External protective earthing and equipotential bonding 16
5.3.5 Supply disconnecting and switching off 16
5.3.6 Protection against electric shock 17
5.3.7 Conductors and cables 17
5.3.8 Control circuits and control functions 17
5.3.9 Operator interface and mounted control devices 18
5.3.10 Control gear - Location, mounting and enclosures 19
5.3.11 Electrical requirements for the installation of load handling devices 19
5.3.12 Electric motors 19
5.4 Non-electrotechnical equipment 19
5.4.1 General 19
5.4.2 Braking systems 20
5.4.3 Hoisting mechanism 21
5.4.4 Luffing system 21
5.4.5 Slew mechanism 22
5.4.6 Travel mechanism 23
5.4.7 Gear drives 23
5.5 Limiting and indicating devices 24
5.5.1 Rated capacity limiters 24
5.5.2 Indicators 25
5.5.3 Motion limiters 25
5.5.4 Performance limiters 25
5.6 Protection against special hazards 26
5.6.1 Hot surfaces 26

5.6.2 Radio equipment ... 26
5.6.3 Laser beams ... 26
5.6.4 Fire hazard ... 26
5.6.5 Exhaust gases ... 26
5.6.6 Fuelling ... 26
5.7 Man-machine interface ... 26
5.7.1 Controls and control stations ... 26
5.7.2 Guarding and access ... 27
5.7.3 Lighting ... 27
5.7.4 Reduction of noise by design ... 28
5.8 Equipment for information and warning ... 29
5.8.1 General ... 29
5.8.2 Location of visual display units ... 29
5.8.3 Safety colour ... 29
5.8.4 Warning lights ... 29

6 Verification of the safety requirements and/or protective measures ... 29
6.1 General ... 29
6.2 Fitness for purpose testing ... 32
6.2.1 General ... 32
6.2.2 Tests ... 32

7 Information for use ... 34
7.1 Instructions for installation and safe use ... 34
7.2 Driver's manual ... 34
7.3 User's manual ... 35
7.4 Instructions for regular checks, inspections and tests ... 36
7.5 Instructions for maintenance ... 36
7.6 Markings ... 37

8 Information to be obtained from the purchaser ... 37

Annex A (informative) Guidance for classification according to EN 13001-1 ... 38

A.1 Total number of working cycles ... 38
A.2 Load spectrum factor kQ ... 39
A.3 Classification of the hoist mechanism ... 40
A.4 Classification of the luffing mechanism ... 41
A.5 Classification of the slewing mechanism ... 43

Annex B (normative) Load combinations ... 46

Annex C (informative) Calculation of stall load factor for indirect acting lifting force limiter ... 47

Annex D (normative) Noise test code for slewing jib cranes ... 49

D.1 General ... 49
D.2 Description of machinery family ... 49
D.3 Determination of a conventional emission sound pressure level by calculation ... 50
D.3.1 Principle of the method ... 50
D.3.2 Calculation ... 50
D.4 Emission sound pressure level determination at control stations and other specified positions by measurement ... 52
D.4.1 Measurement method and points ... 52
D.4.2 Case of very large cranes ... 52
D.4.3 Installation and mounting conditions ... 52
D.4.4 Operating conditions ... 52
D.5 Uncertainties ... 53
D.6 Information to be recorded ... 53
D.7 Information to be reported ... 54
D.8 Declaration and verification of noise emission values ... 54

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC 55

Bibliography 56