ISO 11783-12:2019 (E)

Tractors and machinery for agriculture and forestry — Serial control and communications data network — Part 12: Diagnostics services

Contents

Foreword

Introduction

1 Scope

2 Normative references

3 Terms and definitions

4 Symbols and abbreviated terms

5 General description

6 Requirements

- 6.1 ISO 11783 diagnostics
- 6.2 Network information
- 6.3 Network statistics
- 6.4 Control function information
- 6.5 Functionalities
- 6.6 Control function diagnostics
- 6.7 ISO Latin 1 character set

Annex A (normative) Diagnostic information parameter definitions

- A.1 ECU part number
- A.2 ECU serial number
- A.3 Number of software identification fields
- A.4 Software identification
- A.5 ECU manufacturer name
- A.6 Diagnostic protocol identification
- A.7 ECU location
- A.8 ECU type
- A.9 Number of functionalities
- A.10 Functionalities
- A.11 Functionality generation
- A.12 Number of option bytes
- A.13 ECU hardware ID
- A.14 Product identification code
- A.15 Product identification brand
- A.16 Product identification model

Annex B (normative) Diagnostic information message definitions

- B.1 ECU identification information
- B.2 Software identification
- B.3 ISOBUS certification
- B.4 ISO 11783 NAME
- B.5 Diagnostic protocol
- B.6 Active diagnostic trouble codes (DM1)
- B.7 Previously active diagnostic trouble codes (DM2)
- B.8 Diagnostic data clear/reset previously active DTCs (DM3)
- B.9 Control function functionalities
- B.10 Product identification

Annex C (normative) Network configuration

- **C.1 Network configuration**
- **C.2 Diagnostic connector**

Annex D (informative) Network configuration screen examples — Network information screens

- **D.1 Network information screen**
- **D.2 Network statistics screen**
- **D.3 Network diagnostic screen**
- **D.4 Connected system functionalities screen**
- **D.5 Implement capable functionalities screen**
- **D.6 Functionality alarm mask**

Annex E (normative) Failure mode indicator definitions

- **E.1 Overview**
- **E.2 Definitions used for the FMI descriptions**
- **E.3 FMI descriptions**
- **E.3.1 FMI = 0 (Data valid but above normal operation range — Most severe level)**
- **E.3.2 FMI = 1 (Data valid but below normal operational range — Most severe level)**
- **E.3.3 FMI = 2 (Data erratic, intermittent or incorrect)**
- **E.3.4 FMI = 3 (Voltage above normal or shorted to high source)**
- **E.3.5 FMI = 4 (Voltage below normal or shorted to low source)**
- **E.3.6 FMI = 5 (Current below normal or open circuit)**
- **E.3.7 FMI = 6 (Current above normal or grounded circuit)**
- **E.3.8 FMI = 7 (Mechanical system not responding or improperly adjusted)**
- **E.3.9 FMI = 8 (Abnormal frequency or pulse width or period)**
- **E.3.10 FMI = 9 (Abnormal update rate)**
- **E.3.11 FMI = 10 (Abnormal rate of change)**
- **E.3.12 FMI = 11 (Root cause not known)**
- **E.3.13 FMI = 12 (Bad intelligent unit or component)**
- **E.3.14 FMI = 13 (Out of calibration)**
- **E.3.15 FMI = 14 (Special instructions)**
- **E.3.16 FMI = 15 (Data valid but above normal operating range — Least severe level)**
- **E.3.17 FMI = 16 (Data valid but above normal operating range — Moderately severe level)**
- **E.3.18 FMI = 17 (Data valid but below normal operating range — Least severe level)**
- **E.3.19 FMI = 18 (Data valid but below normal operating range — Moderately severe level)**
- **E.3.20 FMI = 19 (Received network data in error)**
- **E.3.21 FMI = 20-30 (Reserved for future assignment)**
- **E.3.22 FMI = 31 (Condition exists)**

Page count: 31