ISO 18893:2024-10 (E)

Mobile elevating work platforms - Safety principles, inspection, maintenance and operation

Contents

Page

Foreword ..... **v**

Introduction ..... **vi**

1 Scope **1**

2 Normative references **1**

3 Terms and definitions **1**

4 General requirements **5**
4.1 Basic principles 5
4.2 Safe use planning 5
4.3 Manual(s) 6
4.3.1 Operator's manual(s) 6
4.3.2 Parts and service manual(s) 6
4.4 Record retention 6
4.5 Modifications 7
4.5.1 Manufacturer modifications 7
4.5.2 Owner modifications 7

5 Maintenance **7**
5.1 Preventive maintenance 7
5.2 Maintenance inspections 8
5.2.1 General 8
5.2.2 Pre-delivery inspection 8
5.2.3 Pre-start inspection 8
5.2.4 Frequent inspection 9
5.2.5 Annual inspection 9
5.3 Maintenance personnel training 10
5.4 Maintenance and repair safety precautions 10
5.5 Replacement parts 11
5.6 Manufacturer's safety-related bulletins 11

6 Qualification and training **11**
6.1 Authorization to operate 11
6.2 User conformance evaluations 11
6.3 Retraining 11
6.4 Assessment of personnel 11
6.5 Occupant knowledge 12
6.6 Supervisor training 12
6.7 Familiarization 12
6.8 Assistance to operators 13

7 Operation **13**
7.1 General 13
7.2 Risk assessment 13
7.2.1 General 13
7.2.2 Stages of risk assessment planning 13
7.3 Rescue from height 14
7.3.1 General 14
7.3.2 Rescue plan 14
7.3.3 Rescue using another MEWP 15
7.4 Addressing system failure 15
7.5 Before operation 15

7.6 Work site inspection 16
7.7 Understanding of hazardous locations 16
7.8 Specific requirements of operation 17
7.8.1 Weather considerations 17
7.8.2 Ground condition considerations 17
7.8.3 Transporting and travelling on public roads 18
7.8.4 Slope and grade 18
7.8.5 Deployment of stability enhancing means 18
7.8.6 Fall protection 18
7.8.7 Distribution of load 18
7.8.8 MEWP movement 18
7.8.9 Electrocution hazards 19
7.8.10 Footing for personnel 20
7.8.11 Precaution for other moving equipment 20
7.8.12 Reporting safety-related problems or malfunctions 20
7.8.13 Reporting potentially hazardous locations 20
7.8.14 Hazardous location operation 21
7.8.15 Entanglement 21
7.8.16 Load transfer 21
7.8.17 Work area 21
7.8.18 Fuelling 21
7.8.19 Battery charging 21
7.8.20 Improper MEWP stabilisation 21
7.8.21 Misuse as a crane or elevator 21
7.8.22 Use of MEWP for grounding 21
7.8.23 Climbing the extending structure 21
7.8.24 Unusual operating support conditions 21
7.8.25 Travelling 22
7.8.26 Stunt driving 22
7.8.27 Securing the MEWP 22
7.8.28 Interference with safety devices 22
7.8.29 Snagged MEWP 22
7.8.30 Vacating (or entering) a MEWP at height 22
7.8.31 Carrying materials larger than the work platform 23
7.8.32 Carrying materials outside the work platform 23
7.8.33 Rated manual forces and special forces 23
7.8.34 Protection against unauthorized use 23
7.8.35 Misuse as a jack 23
7.8.36 Moving overhead obstructions 23
7.8.37 Parking of MEWP 23
7.8.38 Transport 24
7.8.39 Ventilation 24
7.8.40 Allowable rated forces 24

Annex A (informative) **Examples of MEWP types and groups** **25**

Bibliography **28**