DIN EN ISO 16315:2016-08 (E)

Small craft - Electric propulsion system (ISO 16315:2016)

Contents

Page

European foreword ... **4**

Annex ZA (informative) **Relationship between this European Standard and the Essential Requirements of Directive 2013/53/EU** ... **5**

Foreword ... **7**

Introduction ... **8**

1 Scope ... **9**

2 Normative references ... **9**

3 Terms and definitions ... **10**

4 General requirements ... **13**
4.1 General ... 13
4.2 Components of an electric propulsion system ... 14
4.3 Electric propulsion systems ... 14
4.4 Arrangements for other electrical equipment and circuits on-board a small craft connected to a common energy source for both propulsion and general electrical installation ... 16
4.4.1 DC systems ... 16
4.4.2 AC systems ... 16
4.5 Environmental factors ... 17
4.6 Electrical ratings ... 17
4.7 Equipment ... 18
4.7.1 Transformers ... 18
4.7.2 Converters ... 18
4.7.3 Motors ... 18
4.8 Enclosures ... 18
4.9 Identification of equipment and conductors ... 18
4.10 Segregation of DC and AC systems ... 19
4.11 Steering and throttle controls ... 19
4.12 Electromagnetic compatibility (EMC) ... 19
4.13 Electrical equipment in the vicinity of battery banks ... 19
4.14 Hazardous areas ... 19

5 Controls, monitoring, system alerts and trips alarms ... **20**
5.1 Electrical/electronic controls for electric propulsion systems ... 20
5.1.1 Controls ... 20
5.1.2 Emergency stop ... 21
5.1.3 Fault trip reset ... 21
5.1.4 “Get you home” mode ... 21
5.2 Instruments, alerts and trip alarms ... 21
5.2.1 General ... 21
5.2.2 Operating mode and status ... 21
5.2.3 System alerts ... 22
5.2.4 Fault trip alarms ... 22

6 Protection against electric shock ... **22**
6.1 Protection against direct contact ... 22
6.2 Automatic disconnection of supply to the electric propulsion system under fault-to-earth conditions (earthed two wire DC systems and earthed neutral AC systems) ... 22
6.3 Fault-to-earth monitoring and tripping arrangements for DC fully insulated systems, DC 3-wire systems ... 23
6.4 Fault-to-earth tripping in AC non-neutral earthed systems (IT-type system) ... 24

7 Protection against over-current **24**
7.1 General 24
7.2 Characteristics of protective devices 24
7.3 Overcurrent devices in the outgoing circuit(s) from a battery 25

8 Battery monitoring and installation **25**
8.1 General arrangements 25
8.2 Isolation of battery packs or battery banks 25
8.3 Operational switching of battery pack(s) or battery bank(s) 26
8.4 Permanently energized circuits 26
8.5 Ventilation 27
8.6 Electrical apparatus for explosive gas atmospheres 27

9 Electrical installation **27**
9.1 General 27
9.2 Segregation of electrical propulsion system cables 27

10 Testing **28**
10.1 General 28
10.2 Earthing and bonding 28
10.3 Insulation resistance 28
10.3.1 General 28
10.3.2 DC electrical propulsion systems 28
10.3.3 AC electrical propulsion systems 28
10.3.4 Switchboards, panel boards and distribution boards 28
10.3.5 Power and lighting final circuits 29
10.3.6 Generators and motors 29
10.3.7 Transformers 29
10.4 Electrical/electronic controls systems for propulsion motor control 29
10.5 On load test and inspection of electrical propulsion systems, and associated switch gear and control gear 29
10.6 Voltage drop 29

Annex A (normative) **Information and instructions to be included in the owner's manual** **30**

Annex B (normative) **Installation documentation** **31**

Bibliography **32**