ISO 22472:2016-09 (E)

Ships and marine technology - Guidelines for the operation and installation of voyage data recorder (VDR)

Contents

Page

Foreword v

1 Scope 1

2 Normative references 1

3 Terms,definitionsandabbreviatedterms 2
3.1 Terms and definitions 2
3.2 Abbreviated terms 4

4 VDR interface 4
4.1 General 4
4.2 Input signals required for VDR interfaces 4
4.2.1 Signals defined in applicable parts of IEC 61162 series 4
4.2.2 Signals other than IEC 61162 format 5
4.2.3 Bridge audible sound captured by microphones 6
4.2.4 VHF radio connection 6
4.2.5 Radar display connection 6
4.2.6 ECDIS display connection 6
4.3 Main alarms 7
4.4 AIS 7
4.5 Bridge alert management interface 7

5 DetailsofinterfacesbetweensensorsandVDR 7
5.1 General 7
5.2 Date and time (IEC 61996-1:2013, 4.6.1) 7
5.3 Ship's position (IEC 61996-1:2013, 4.6.2) 8
5.4 Speed (IEC 61996-1:2013, 4.6.3) 8
5.5 Heading (IEC 61996-1:2013, 4.6.4) 8
5.6 Bridge audio (IEC 61996-1:2013, 4.6.5) 9
5.7 VHF communication audio (IEC 61996-1:2013, 4.6.6) 9
5.8 Radar data-post-display selection (IEC 61996-1:2013, 4.6.7) 9
5.9 ECDIS (IEC 61996-1:2013, 4.6.8) 11
5.10 Depth (Echo sounder) (IEC 61996-1:2013, 4.6.9) 12
5.11 Main alarms on the bridge (IEC 61996-1:2013, 4.6.10) 12
5.12 Rudder order and response (IEC 61996-1:2013, 4.6.11) 13
5.12.1 Rudder order and response from HCS or TCS (if installed) 13
5.12.2 Rudder order and response from steering system 13
5.13 Engine and thruster order and response (IEC 61996-1:2013, 4.6.12) 14
5.13.1 Engine order and response 14
5.13.2 Thruster order and response 14
5.14 Hull openings (doors) status (IEC 61996-1:2013, 4.6.13) 15
5.15 Watertight and fire door status (IEC 61996-1:2013, 4.6.14) 15
5.15.1 Watertight and fire door status 15
5.16 Accelerations and hull stresses (IEC 61996-1:2013, 4.6.15) 16
5.17 Wind speed and direction (IEC 61996-1:2013, 4.6.16) 16
5.18 AIS data (IEC 61996-1:2013, 4.6.17) 16
5.19 Rolling motion (IEC 61996-1:2013, 4.6.18) 17
5.20 Configuration (IEC 61996-1:2013, 4.6.19) 17
5.21 Electronic logbook (IEC 61996-1:2013, 4.6.20) 17

6 Installation 18
6.1 Required VDR equipment 18
6.2 Power supply of the VDR and interfaces 18
6.2.1 Power supply from the ship's emergency source of electrical power 18
6.2.2 Power supply from the reserve power source 18
6.3 Installation of the protective capsule and float free capsule (IEC 61996-1:2013, 5.1.1) 18
6.4 Positions of microphones (IEC 61996-1:2013, 4.6.5) 19
6.5 Cable connections 19
6.6 Ship specific documentation 19
6.6.1 Planning and approval documentation 19

7 Acceptance test (Commissioning) 20

8 Performance Tests 20
8.1 General 20
8.2 Operational Performance Test (IEC 61996-1:2013, 5.12) 20
8.3 Annual Performance Test 20

9 Downloadandplaybackequipmentforinvestigationauthorities 21
9.1 General 21
9.2 Information for use by an investigation authority (IEC 61996-1) 21

Annex A (informative) Mandatory alarms (IEC 61996-1:2013, Annex B) 22

Annex B (informative) LAN image protocol (IEC 61996-1:2013, Annex E) 25

Annex C (informative)Networkforimagetransmission(IEC61996-1:2013,AnnexF) 30

Annex D (informative) ECDIS display source information (IEC 61996-1:2013, Annex G) 33

Annex E (informative) Manufacturer's documentation (IEC 61996-1:2013, 5.5) 38

Annex F (informative) Performance test report (IMO Circular MSC.1/Circ.1222 Appendix) 40

Bibliography 45