ISO 4309:2010-08 (E)

Cranes - Wire ropes - Care and maintenance, inspection and discard

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 2

3 Terms and definitions 2

4 Care and maintenance 3
4.1 General 3
4.2 Rope replacement 3
4.3 Offloading and storing the rope 5
4.4 Condition of the rope prior to installation 5
4.5 Installing the rope 5
4.6 Running-in the new rope 8
4.7 Maintaining the rope 9
4.8 Maintenance of rope-related parts of the crane 9

5 Inspection 10
5.1 General 10
5.2 Daily visual inspection 10
5.3 Periodic inspection 10
5.4 Inspection following an incident 13
5.5 Inspection following period with crane out of operation 13
5.6 Non-destructive testing 13

6 Discard criteria 14
6.1 General 14
6.2 Visible broken wires 14
6.3 Decrease in rope diameter 17
6.4 Fracture of strands 19
6.5 Corrosion 19
6.6 Deformation and damage 20

Annex A (informative) Key areas requiring particular close inspection 23

Annex B (informative) Typical modes of deterioration 25

Annex C (informative) Internal examination of rope 34

Annex D (informative) Typical examples of inspection record 37

Annex E (informative) Useful information on rope deterioration and discard criteria 39

Annex F (informative) Combined effect assessment of rope condition and severity rating -- One method 42

Annex G (informative) Examples of cross-sections of ropes and corresponding rope category number (RCN) 45

Annex H (informative) Guidance on assessment and rating of external corrosion 51

Bibliography 53