

ISO 11665-3:2020-01 (E)

Measurement of radioactivity in the environment - Air: radon-222 - Part 3: Spot measurement method of the potential alpha energy concentration of its short-lived decay products

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms, definitions and symbols	1
3.1	Terms and definitions	1
3.2	Symbols	2
4	Principle of the measurement method	3
5	Equipment	3
6	Sampling	4
6.1	General	4
6.2	Sampling objective	4
6.3	Sampling characteristics	4
6.4	Sampling conditions	5
6.4.1	General	5
6.4.2	Installation of sampling system	5
6.4.3	Sampling duration	5
6.4.4	Volume of air sampled	5
7	Detection method	5
8	Measurement	5
8.1	Procedure	5
8.2	Influence quantities	6
8.3	Calibration	6
9	Expression of results	7
9.1	General	7
9.2	Potential alpha energy concentration	7
9.3	Standard uncertainty	7
9.4	Decision threshold	8
9.5	Detection limit	9
9.6	Limits of the confidence interval	9
10	Test report	9
Annex A (informative)	Examples of gross alpha counting protocols	11
Annex B (informative)	Calculation of the coefficients $k_{218\text{Po},j}$, $k_{214\text{Pb},j}$ and $k_{214\text{Bi},j}$	12
Annex C (informative)	Measurement method using gross alpha counting according to the Thomas protocol	16
Bibliography		19