

ISO/TS 21805:2018 (E)

Guidance on design, selection and installation of vents to safeguard the structural integrity of enclosures protected by gaseous fire-extinguishing systems

Contents

	Foreword
	Introduction
1	Scope
2	Normative references
3	Terms and definitions
4	Symbols and abbreviated terms
5	Use and limitations
6	Safety
6.1	Structural safety
6.2	Personnel safety
7	System design — Pressure-relief venting
7.1	General
7.2	Extinguishant characteristics
7.2.1	Pressure graphs
7.3	Enclosure characteristics
7.4	Pressure-relief vent paths
7.5	Types of pressure-relief vents
7.5.1	General
7.5.2	Gravity vents
7.5.3	Counter weighted flap vent
7.5.4	Electrically operated vents
7.5.5	Pneumatically operated vent
7.5.6	Vent accessories
7.5.6.1	Security provisions
7.5.6.2	Insect screen
7.5.6.3	Weather louvres
7.5.6.4	Decorative grilles
7.5.6.5	Limit switches
7.6	Pressure-relief vent characteristics
7.6.1	Vent efficiency
7.6.2	Minimum opening pressure
7.6.3	Minimum closing pressure
7.6.4	Fire rating
7.7	Vent location and mounting
7.7.1	Vent location
7.7.2	Vent mounting
7.8	Pressure-relief vent area calculations
7.8.1	Use of agent-specific equations
7.8.2	Vent area requirement (non-liquefiable gases and CO ₂)
7.8.2.1	Example calculations for inert gases (values taken from ISO 14520)
7.8.2.2	Example calculations for carbon dioxide (based on ISO 6183)
7.8.3	Vent area requirements (liquefiable gases)
7.8.3.1	FK-5-1-12
7.8.3.1.1	FK-5-1-12: Limits of applicability

7.8.3.1.2	Pressure excursion for FK-5-1-12
7.8.3.1.3	Total pressure-relief vent area for FK-5-1-12
7.8.3.2	HFC-227ea
7.8.3.2.1	HFC-227ea: Limits of applicability
7.8.3.2.2	Pressure excursion for HFC-227ea
7.8.3.2.3	Total pressure-relief vent area for HFC-227ea
7.8.3.3	HFC-23
7.8.3.3.1	HFC-23: Limits of applicability
7.8.3.3.2	Pressure excursion for HFC-23
7.8.3.3.3	Total pressure-relief vent area for HFC-23
7.8.3.4	HFC-125
7.8.3.4.1	HFC-125: Limits of applicability
7.8.3.4.2	Pressure excursion for HFC-125
7.8.3.4.3	Total vent area for HFC-125
7.8.3.5	Example calculation 1: Determination of positive and negative pressure when the pressure-relief area is known
7.8.3.6	Example calculation 2: Determination pressure-relief area required following discharge to limit the pressure excursion
7.8.4	Leakage
7.9	Cascade venting calculations
7.9.1	Example calculation 3
7.9.2	Cascade vent arrangements
7.9.3	Venting into adjacent enclosures
7.9.3.1	Over-pressurisation: Determination of adjacent enclosure volume
7.9.3.2	Under-pressurisation: Determination of adjacent enclosure volume
7.9.3.3	Example calculation 4
7.9.3.4	Example calculation 5
8	System design — Post discharge venting
9	Acceptance
10	Service and maintenance