

ISO/TR 19032:2006-10 (E)

Plastics - Use of polyethylene reference specimens (PERS) for monitoring laboratory and outdoor weathering conditions

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Background information	1
3	Material	1
3.1	Preparation of PERS	1
4	Procedure	2
4.1	Method for measuring the carbonyl index of PERS	2
4.2	Round Robin Test of laboratory light-source exposure devices with PERS	3
4.2.1	Xenon-arc-lamp exposure	3
4.2.2	Open-flame carbon-arc-lamp exposure	3
4.2.3	Fluorescence lamp exposure	4
4.3	Outdoor exposure test of PERS	4
4.4	Consistency of laboratory light-source exposure devices	5
5	Results and discussion	6
5.1	Result of RRT of laboratory light-source exposure devices with PERS	6
5.1.1	Xenon-arc-lamp exposure	6
5.1.2	Open-flame carbon-arc-lamp exposure	10
5.1.3	Fluorescent lamp exposure	10
5.2	Characterizing the conditions of outdoor exposure test site	11
5.3	Examples of correlation between outdoor exposure test and laboratory light-source exposure test using PERS	12
5.4	Control limit of particular laboratory light-source exposure apparatus	13
6	Conclusion	14
6.1	Results of RRT	14
6.2	Outdoor exposure of PERS	15
6.3	Correlation between outdoor and xenon-arc-lamp exposure for PERS	15
6.4	Consistency of laboratory light-source exposure devices	15
Bibliography		16