

DIN EN 16116-2:2014-01 (E)

Railway applications - Design requirements for steps, handrails and associated access for staff - Part 2: Freight wagons

Contents		Page
Foreword		3
Introduction		4
1	Scope	5
2	Normative references	5
3	Terms and definitions	5
4	Steps and handrails	6
4.1	General requirements	6
4.2	Steps	6
4.2.1	General	6
4.2.2	Shunter's step	7
4.2.3	Other steps	10
4.3	Handrails	10
4.3.1	General	10
4.3.2	Shunter handrail	10
4.3.3	Other handrails	11
5	Shunter's stand	12
5.1	General	12
5.2	Shunter's stand at wagons with end wall boards	14
5.3	Shunter's stand with tilting handrail	15
5.4	Shunter's stand for special case flat wagons with fixed handrails	16
6	Reserved spaces	16
6.1	General	16
6.2	Space for shunting staff operation	16
6.2.1	Space for shunter during coupling (Berne Rectangle)	16
6.2.2	Space for the shunter during temporary travel	17
6.3	Clearances for tail light and draw hook	19
6.3.1	Position, space envelope and clearance for the tail light	19
6.3.2	Clearance for draw hook	21
Annex A (normative)	Calculation of space for shunter (Berne Rectangle) in curves when using screw couplings	22
Annex B (informative)	Gangways and other access solutions	24
B.1	General	24
B.2	Steps for gangways and platforms	24
B.3	Steps for access to the wagon floor	26
B.4	Steps at wagon end	26
Annex ZA (informative)	Relationship between this European Standard and the Essential Requirements of EU Directive 2008/57/EC	29