

DIN EN ISO 16000-2:2006-06 (E)

Indoor air - Part 2: Sampling strategy for formaldehyde (ISO 16000-2:2004)

| Contents | | Page |
|--|---|-------------|
| Foreword | | 2 |
| Introduction | | 4 |
| 1 | Scope | 5 |
| 2 | Normative references | 5 |
| 3 | Sources and occurrence of formaldehyde | 5 |
| 4 | Measurement techniques | 7 |
| 4.1 | General | 7 |
| 4.2 | Short-term monitoring | 8 |
| 4.3 | Long-term monitoring | 8 |
| 4.4 | Methods for screening tests | 8 |
| 5 | Sampling strategy | 8 |
| 5.1 | General | 8 |
| 5.2 | Objectives of the measurement and conditions | 8 |
| 5.3 | Time of sampling | 10 |
| 5.4 | Duration of sampling and frequency of measurement | 10 |
| 5.5 | Sampling location | 10 |
| 5.6 | Reporting on results and uncertainties | 10 |
| 5.7 | Quality assurance | 11 |
| Annex A (informative) Properties of formaldehyde | | 12 |
| Annex B (informative) Overview of important sources and typical concentrations | | 13 |
| Annex C (informative) Correlation of formaldehyde concentrations in naturally ventilated rooms depending on ventilation | | 14 |
| Annex D (informative) Dependence of the confidence interval on the number of samples | | 15 |
| Annex E (informative) Examples of screening tests | | 16 |
| Bibliography | | 18 |