

# DIN EN 16302:2013-04 (E)

## Conservation of cultural heritage - Test methods - Measurement of water absorption by pipe method

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
Introduction .....		4
1	Scope .....	5
2	Normative references .....	5
3	Terms and definitions .....	5
4	Principle .....	5
5	Symbols and abbreviations .....	6
6	Test equipment .....	6
6.1	General .....	6
6.2	Pipe for vertical surfaces (type V) .....	6
6.3	Pipe for horizontal surfaces (type H) .....	7
6.4	Water reservoir .....	8
6.5	Sealing material .....	9
6.6	Chronometer .....	10
7	Experimental conditions .....	10
7.1	General .....	10
7.2	"In situ" measurements .....	10
Laboratory measurements .....		10
7.3	Specimen pre-conditioning .....	10
7.4	Test procedure .....	10
8	Expression of the results .....	11
8.1	General .....	11
8.2	Calculation of water absorption per unit of surface area $W_i$ , at the time $t_i$ .....	11
8.3	Calculation of total water absorption per unit of surface area $W_f$ , at time $t_f$ .....	11
9	Test report .....	11
Annex A (informative) Common types of pipes .....		13
A.1	TYPE "V1" - KARSTEN TUBE .....	13
A.2	TYPE "V2" - "Large surface for heterogeneous materials" .....	14
A.3	TYPE "V3" - "Italian pipe" .....	14
Bibliography .....		15