DIN SPEC 58961:2013-04 (E)

Technical Report - Thrombocyte diagnostics

Contents

Page

Foreword 3

1 Scope 4

2 Symbols and abbreviations 4

3 Pre-analytical procedures in platelet function testing 5
3.1 Patient preparation in platelet function testing 5
3.2 Blood extraction 5
3.2.1 Light transmission aggregometry (Born's method) (LTA) 5
3.2.2 Multiple electrode aggregometry (MEA) and impedance aggregometry 6
3.2.3 Platelet function analyser (PFA systems) 6
3.3 Determination of platelet count and packed cell volume 6
3.4 Transporting samples 6
3.5 Sample preparation 6
3.5.1 Light transmission aggregometry (Born's method) (LTA) 6
3.5.2 Impedance aggregometry 7
3.5.3 PFA systems 7
3.6 Reference range 7

4 Activation paths for platelet function testing 7

5 Platelet aggregation methods 9
5.1 Light transmission aggregometry (Born's method) (LTA) 9
5.1.1 General 9
5.1.2 Principle 9
5.1.3 Equipment, materials and reagents 9
5.1.4 Sample preparation 9
5.1.5 Procedure 9
5.1.6 Interpretation 10
5.1.7 Quality control 16
5.2 Aggregation methods -- Electrical impedance aggregometry (Cardinal's method) and multiple electrode aggregometry (MEA) 16
5.2.1 General 16
5.2.2 Principle 16
5.2.3 Equipment, materials and reagents 16
5.2.4 Sample preparation 17
5.2.5 Procedure 17
5.2.6 Interpretation 18
5.2.7 Quality control 19

6 The PFA system 20
6.1 General 20
6.2 Procedure 20
6.3 Interpretation of results 21
6.3.1 Expected results 21
6.3.2 Reference ranges and cut-off values 22
6.4 Clinical applications of PFA test cartridges 23
6.5 Quality control 23

7 Interfering factors 23
7.1 General 23

7.2 Method-specific interfering factors 24
7.2.1 LTA 24
7.2.2 Impedance aggregometry 24
7.2.3 PFA systems 24

Bibliography 25