

# DIN EN 14761:2006-05 (E)

## Wood flooring - Solid wood parquet - Vertical finger, wide finger and module brick

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
<b>1</b>	<b>Scope .....</b>	<b>4</b>
<b>2</b>	<b>Normative references .....</b>	<b>4</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>5</b>
<b>4</b>	<b>Symbols and abbreviations .....</b>	<b>5</b>
<b>5</b>	<b>Specific product requirements .....</b>	<b>6</b>
5.1	Wood species .....	6
5.2	Appearance .....	6
5.2.1	General rules .....	6
5.2.2	Rules for wide fingers and module bricks .....	6
5.2.3	Rules for vertical finger .....	8
5.2.4	Free class .....	8
5.3	Moisture content .....	8
5.4	Geometrical characteristics .....	8
5.4.1	General .....	8
5.4.2	Vertical finger .....	8
5.4.3	Wide finger .....	9
5.4.4	Module brick .....	10
5.4.5	Vertical finger laying unit - like a ladder .....	11
5.4.6	Wide finger laying unit - like a ladder .....	12
5.4.7	Module parquet laying unit - made up from component squares .....	12
5.4.8	Machining .....	12
5.5	Technical specifications and properties .....	12
5.5.1	Technical characteristics required when in service .....	12
5.5.2	Specific site requirements .....	12
5.5.3	Appearance .....	12
5.5.4	Renovation and repair .....	13
<b>6</b>	<b>Marking .....</b>	<b>13</b>
<b>Annex A (informative)</b>	<b>Botanical and trade names of the most commonly used species for wood flooring (hardwood and softwood species) .....</b>	<b>14</b>
<b>Annex B (normative)</b>	<b>Principles for the classification of the free class .....</b>	<b>20</b>
<b>Bibliography .....</b>		<b>21</b>