

DIN EN 14761:2006-05 (E)

Wood flooring - Solid wood parquet - Vertical finger, wide finger and module brick

Contents	Page
Foreword	3
1 Scope	4
2 Normative references	4
3 Terms and definitions	5
4 Symbols and abbreviations	5
5 Specific product requirements	6
5.1 Wood species	6
5.2 Appearance	6
5.2.1 General rules	6
5.2.2 Rules for wide fingers and module bricks	6
5.2.3 Rules for vertical finger	8
5.2.4 Free class	8
5.3 Moisture content	8
5.4 Geometrical characteristics	8
5.4.1 General	8
5.4.2 Vertical finger	8
5.4.3 Wide finger	9
5.4.4 Module brick	10
5.4.5 Vertical finger laying unit - like a ladder	11
5.4.6 Wide finger laying unit - like a ladder	12
5.4.7 Module parquet laying unit - made up from component squares	12
5.4.8 Machining	12
5.5 Technical specifications and properties	12
5.5.1 Technical characteristics required when in service	12
5.5.2 Specific site requirements	12
5.5.3 Appearance	12
5.5.4 Renovation and repair	13
6 Marking	13
Annex A (informative) Botanical and trade names of the most commonly used species for wood flooring (hardwood and softwood species)	14
Annex B (normative) Principles for the classification of the free class	20
Bibliography	21