

# DIN 29548-3:1993-03 (D/E)

Luft- und Raumfahrt; Durchsetzungen; Konstruktionshinweise und Beispiele

Aerospace; offsettings; directions for design and examples

---

Inhalt	Seite
1 Anwendungsbereich und Zweck .....	1
2 Fließverhalten beim Fertigungsverfahren.....	1
3 Zeichnungseintragung .....	1
3.1 Grundform 1 .....	2
3.2 Grundform 2 .....	2
3.3 Grundform 3 .....	2
3.4 Grundform 4 .....	3
4 Konstruktionsbeispiele .....	3
4.1 Einfache rechteckige Durchsetzung zum Profil .....	4
4.2 Doppelte rechteckige Durchsetzung zum Profil, Sonderwerkzeuge erforderlich. ....	4
4.3 Einfache nicht rechteckige Durchsetzung zum Profil, Sonderwerkzeug erforderlich. ....	4
4.4 Doppelte rechteckige Durchsetzung bei Preßprofilen, Sonderwerkzeug erforderlich. ....	5
Zitierte Normen .....	5

Contents	Page
1 Field of application and scope .....	1
2 Yield behaviour during the manufacturing process .....	1
3 Drawing indications 1	
3.1 Basic form 1 .....	2
3.2 Basic form 2 .....	2
3.3 Basic form 3 .....	2
3.4 Basic form 4 .....	3
4 Examples of design .....	3
4.1 Single offsetting perpendicular to section .....	4
4.2 Double offsetting perpendicular to section, special tool required. ....	4
4.3 Single offsetting not perpendicular to section, special tool required. ....	4
4.4 Double offsetting perpendicular to section on extrusions, special tool required. ....	5
Quoted Standards .....	5