

# DIN EN ISO 1833-8:2011-01 (E)

Textiles - Quantitative chemical analysis - Part 8: Mixtures of acetate and triacetate fibres (method using acetone) (ISO 1833-8:2 006)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
1 <b>Scope</b> .....		5
2 <b>Normative references</b> .....		5
3 <b>Principle</b> .....		5
4 <b>Reagents</b> .....		5
5 <b>Apparatus</b> .....		5
6 <b>Test Procedure</b> .....		6
7 <b>Calculation and expression of results</b> .....		6