

# DIN EN ISO 1833-8:2011-01 (E)

Textiles - Quantitative chemical analysis - Part 8: Mixtures of acetate and triacetate fibres (method using acetone) (ISO 1833-8:2 006)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
1	Scope .....	5
2	Normative references .....	5
3	Principle .....	5
4	Reagents .....	5
5	Apparatus .....	5
6	Test Procedure .....	6
7	Calculation and expression of results .....	6