

ISO 13503-1:2003-09 (E)

Petroleum and natural gas industries - Completion fluids and materials - Part 1: Measurement of viscous properties of completion fluids

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Terms and definitions	1
3	Abbreviated terms	2
4	Measurement and precision	2
5	Fluid preparation	2
6	Fluid preparation using shear-history simulation (optional)	3
6.1	General	3
6.2	Requirements for proper shear-history simulation	3
6.3	Conditions for sample delivery	3
6.4	Conditions for standard shear-history simulation	3
6.5	Operational considerations	4
7	Instrument calibration	5
8	Measurement procedures	5
8.1	General	5
8.2	Non-crosslinked fluids (see 2.6)	5
8.3	Viscoelastic fluids	10
9	Calculation procedures	11
9.1	General concepts	11
9.2	Brief review of geometry-independent rheology vs. nominal rheology	12
9.3	Limitations/problems that may produce erroneous results	13
9.4	Calculation method for concentric-cylinder viscometers	13
9.5	Bingham plastic parameters for completion fluids	16
9.6	Calculations for optional shear-history simulation	16
10	Test report	17
Bibliography		20