ISO/TR 19032:2026-06 (E)

Plastics - Use of polyethylene reference film (PERF) for monitoring laboratory and outdoor weathering conditions

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 Abbreviated terms 1

5 Background information 1

6 Material 2
6.1 Properties 2
6.2 Preparation 3

7 Method for measuring the carbonyl index of PERF 3

8 Interlaboratory tests: exposure of PERF to laboratory light-sources 4
8.1 General 4
8.2 Protocol for the artificial exposures 5
8.2.1 General 5
8.2.2 Xenon-arc lamp exposure 5
8.2.3 Fluorescent UV lamp exposure 5
8.2.4 Medium pressure mercury vapour lamp exposure 6
8.2.5 Measurement of the carbonyl index Ci 6
8.3 Outdoor exposure test of PERF 6
8.4 Results and discussion 6
8.4.1 Artificial exposures of PERF to laboratory light-source 6
8.4.2 Exposure of PERF to natural outdoor conditions 17
8.5 Conclusion 19

Annex A (informative) History of polyethylene reference specimens (PERS) 21

Bibliography 23