

ISO/TR 19032:2026-06 (E)

Plastics - Use of polyethylene reference film (PERF) for monitoring laboratory and outdoor weathering conditions

Contents	Page
Foreword	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Abbreviated terms	1
5 Background information	1
6 Material	2
6.1 Properties	2
6.2 Preparation	3
7 Method for measuring the carbonyl index of PERF	3
8 Interlaboratory tests: exposure of PERF to laboratory light-sources	4
8.1 General	4
8.2 Protocol for the artificial exposures	5
8.2.1 General	5
8.2.2 Xenon-arc lamp exposure	5
8.2.3 Fluorescent UV lamp exposure	5
8.2.4 Medium pressure mercury vapour lamp exposure	6
8.2.5 Measurement of the carbonyl index Ci	6
8.3 Outdoor exposure test of PERF	6
8.4 Results and discussion	6
8.4.1 Artificial exposures of PERF to laboratory light-source	6
8.4.2 Exposure of PERF to natural outdoor conditions	17
8.5 Conclusion	19
Annex A (informative) History of polyethylene reference specimens (PERS)	21
Bibliography	23