

# DIN EN ISO 16000-12:2008-08 (E)

Indoor air - Part 12: Sampling strategy for polychlorinated biphenyls (PCBs), polychlorinated dibenzo-p-dioxins (PCDDs), polychlorinated dibenzofurans (PCDFs) and polycyclic aromatic hydrocarbons (PAHs) (ISO 16000-12:2008)

---

<b>Contents</b>	<b>Page</b>
<b>Foreword</b> .....	<b>3</b>
<b>Introduction</b> .....	<b>4</b>
<b>1 Scope</b> .....	<b>5</b>
<b>2 Normative references</b> .....	<b>5</b>
<b>3 Sources and incidence of PCBs, PCDDs/PCDFs and PAHs</b> .....	<b>5</b>
<b>4 Measurement procedure</b> .....	<b>7</b>
<b>5 Measurement planning</b> .....	<b>8</b>
<b>Annex A (informative) Structures, toxicity and calculation of toxic equivalents</b> .....	<b>13</b>
<b>Annex B (informative) Procedure for investigating possible sources of indoor PCB pollution with a view to possible renovation</b> .....	<b>17</b>
<b>Annex C (informative) Indoor investigations for PCDDs/PCDFs after fires</b> .....	<b>19</b>
<b>Bibliography</b> .....	<b>20</b>