

DIN SPEC 58961:2013-04 (E)

Technical Report - Thrombocyte diagnostics

Contents		Page
Foreword		3
1	Scope	4
2	Symbols and abbreviations	4
3	Pre-analytical procedures in platelet function testing	5
3.1	Patient preparation in platelet function testing	5
3.2	Blood extraction	5
3.2.1	Light transmission aggregometry (Born's method) (LTA)	5
3.2.2	Multiple electrode aggregometry (MEA) and impedance aggregometry	6
3.2.3	Platelet function analyser (PFA systems)	6
3.3	Determination of platelet count and packed cell volume	6
3.4	Transporting samples	6
3.5	Sample preparation	6
3.5.1	Light transmission aggregometry (Born's method) (LTA)	6
3.5.2	Impedance aggregometry	7
3.5.3	PFA systems	7
3.6	Reference range	7
4	Activation paths for platelet function testing	7
5	Platelet aggregation methods	9
5.1	Light transmission aggregometry (Born's method) (LTA)	9
5.1.1	General	9
5.1.2	Principle	9
5.1.3	Equipment, materials and reagents	9
5.1.4	Sample preparation	9
5.1.5	Procedure	9
5.1.6	Interpretation	10
5.1.7	Quality control	16
5.2	Aggregation methods -- Electrical impedance aggregometry (Cardinal's method) and multiple electrode aggregometry (MEA)	16
5.2.1	General	16
5.2.2	Principle	16
5.2.3	Equipment, materials and reagents	16
5.2.4	Sample preparation	17
5.2.5	Procedure	17
5.2.6	Interpretation	18
5.2.7	Quality control	19
6	The PFA system	20
6.1	General	20
6.2	Procedure	20
6.3	Interpretation of results	21
6.3.1	Expected results	21
6.3.2	Reference ranges and cut-off values	22
6.4	Clinical applications of PFA test cartridges	23
6.5	Quality control	23
7	Interfering factors	23
7.1	General	23

7.2	Method-specific interfering factors	24
7.2.1	LTA	24
7.2.2	Impedance aggregometry	24
7.2.3	PFA systems	24
	Bibliography	25