

# ISO 11704:2010-07 (E)

## Water quality - Measurement of gross alpha and beta activity concentration in non-saline water - Liquid scintillation counting method

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Symbols, definitions and units .....</b>	<b>2</b>
<b>4</b>	<b>Principle .....</b>	<b>2</b>
<b>5</b>	<b>Reagents and equipment .....</b>	<b>3</b>
<b>6</b>	<b>Sampling .....</b>	<b>4</b>
<b>7</b>	<b>Procedure .....</b>	<b>4</b>
<b>7.1</b>	<b>Direct counting .....</b>	<b>4</b>
<b>7.2</b>	<b>Thermal preconcentration .....</b>	<b>5</b>
<b>7.3</b>	<b>Sample preparation .....</b>	<b>5</b>
<b>7.4</b>	<b>Liquid scintillation measurement .....</b>	<b>5</b>
<b>8</b>	<b>Expression of results .....</b>	<b>7</b>
<b>8.1</b>	<b>Calculation of activity per unit of mass .....</b>	<b>7</b>
<b>8.2</b>	<b>Standard uncertainty .....</b>	<b>8</b>
<b>8.3</b>	<b>Decision threshold .....</b>	<b>8</b>
<b>8.4</b>	<b>Detection limit .....</b>	<b>9</b>
<b>8.5</b>	<b>Confidence limits .....</b>	<b>9</b>
<b>8.6</b>	<b>Quality control .....</b>	<b>10</b>
<b>9</b>	<b>Interference control .....</b>	<b>10</b>
<b>9.1</b>	<b>Contamination .....</b>	<b>10</b>
<b>9.2</b>	<b>Ingrowth of radon .....</b>	<b>10</b>
<b>9.3</b>	<b>Loss of polonium .....</b>	<b>10</b>
<b>10</b>	<b>Test report .....</b>	<b>10</b>
<b>Bibliography .....</b>		<b>12</b>