

ISO/TR 9212:2015-06 (E)

Hydrometry - Methods of measurement of bedload discharge

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Measurement of bedload	1
4.1	General	1
4.2	Direct measurement methods	1
4.3	Indirect measurement methods	2
5	Design and strategy of measurement of bedload discharge	2
6	Site selection	2
7	Bedload samplers and traps	3
7.1	Bedload samplers	3
7.1.1	Requirements of an ideal bedload sampler	3
7.1.2	Basket or box type sampler	3
7.1.3	Frame and net sampler	4
7.1.4	Pressure-difference sampler	4
7.1.5	Advantages and disadvantages	5
7.1.6	Characteristics of bedload samplers	9
7.2	Measurement using bedload trap	10
7.2.1	Vortex tube bedload trap	10
7.2.2	Pit and Trough trap	11
7.2.3	Advantages and disadvantages	12
8	Procedures for measurement of bedload discharge using bedload samplers	12
8.1	General	12
8.2	Sample identification	13
8.3	Calculations	14
8.4	Errors	15
9	Indirect measurement of bedload	16
9.1	General	16
9.2	Differential measurement	16
9.3	Volumetric measurement	16
9.4	Dune-tracking	17
9.4.1	Moving boat	17
9.4.2	In situ echo sounder	17
9.4.3	Accuracy of the dune-tracking methods	18
9.5	Tracers	18
9.6	Remote sensing LiDAR	18
9.7	Acoustic instruments	19
9.8	Acoustic Doppler current profiler	19
Annex A (informative)	Bedload-surrogate monitoring technologies[8]	20
Bibliography		24