

DIN 29548-3:1993-03 (D/E)

Luft- und Raumfahrt; Durchsetzungen; Konstruktionshinweise und Beispiele

Aerospace; offsettings; directions for design and examples

Inhalt	Seite
1 Anwendungsbereich und Zweck	1
2 Fließverhalten beim Fertigungsverfahren.....	1
3 Zeichnungseintragung	1
3.1 Grundform 1	2
3.2 Grundform 2	2
3.3 Grundform 3	2
3.4 Grundform 4	3
4 Konstruktionsbeispiele	3
4.1 Einfache rechtwinklige Durchsetzung zum Profil	4
4.2 Doppelte rechtwinklige Durchsetzung zum Profil, Sonderwerkzeuge erforderlich.	4
4.3 Einfache nicht rechtwinklige Durchsetzung zum Profil, Sonderwerkzeug erforderlich.	4
4.4 Doppelte rechtwinklige Durchsetzung bei Preßprofilen, Sonderwerkzeug erforderlich.	5
Zitierte Normen	5

Contents	Page
1 Field of application and scope	1
2 Yield behaviour during the manufacturing process	1
3 Drawing indications 1	
3.1 Basic form 1	2
3.2 Basic form 2	2
3.3 Basic form 3	2
3.4 Basic form 4	3
4 Examples of design	3
4.1 Single offsetting perpendicular to section	4
4.2 Double offsetting perpendicular to section, special tool required.	4
4.3 Single offsetting not perpendicular to section, special tool required.	4
4.4 Double offsetting perpendicular to section on extrusions, special tool required.	5
Quoted Standards	5