DIN 29548-3:1993-03 (D/E)

Luft- und Raumfahrt; Durchsetzungen; Konstruktionshinweise und Beispiele

Aerospace; offsettings; directions for design and examples

Inhalt

Seite

1 Anwendungsbereich und Zweck 1

2 Fließverhalten beim Fertigungsverfahren 1

3 Zeichnungseintragung 1
3.1 Grundform 1 2
3.2 Grundform 2 2
3.3 Grundform 3 2
3.4 Grundform 4 3

4 Konstruktionsbeispiele 3
4.1 Einfache rechtwinklige Durchsetzung zum Profil 4
4.2 Doppelte rechtwinklige Durchsetzung zum Profil, Sonderwerkzeuge erforderlich. 4
4.3 Einfache nicht rechtwinklige Durchsetzung zum Profil, Sonderwerkzeug erforderlich. 4
4.4 Doppelte rechtwinklige Durchsetzung bei Preßprofilen, Sonderwerkzeug erforderlich. 5

Zitierte Normen 5

Contents

Page

1 Field of application and scope 1

2 Yield behaviour during the manufacturing process 1

3 Orawing indications 1
3.1 Basic form 1 2
3.2 Basic form 2 2
3.3 Basic form 3 2
3.4 Basic form 4 3

4 Examples of design 3
4.1 Single offsetting perpendicular to section 4
4.2 Double offsetting perpendicular to section, special tool required. 4
4.3 Single offsetting not perpendicular to section, special tool required. 4
4.4 Double offsetting perpendicular to section on extrusions, special tool required. 5

Quoted Standards 5