

ISO 22489:2016-10 (E)

Microbeam analysis - Electron probe microanalysis - Quantitative point analysis for bulk specimens using wavelength dispersive X-ray spectroscopy

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Abbreviated terms	1
4	Procedure for quantification	2
4.1	General procedure for quantitative microanalysis	2
4.1.1	Principle and procedure of quantitative microanalysis	2
4.1.2	Coverage of the quantitative analysis	2
4.1.3	Selection of reference materials	3
4.2	Specimen preparation	3
4.3	Calibration of the instrument	3
4.3.1	Accelerating voltage	3
4.3.2	Probe current	3
4.3.3	X-ray spectrometer	3
4.3.4	Dead time	4
4.4	Analysis conditions	4
4.4.1	Accelerating voltage	4
4.4.2	Probe current	4
4.4.3	Analysis position	4
4.4.4	Probe diameter	5
4.4.5	Scanning the focused electron beam	5
4.4.6	Specimen surface	5
4.4.7	Selection of X-ray line	5
4.4.8	Spectrometer	5
4.4.9	Method for measurement of X-ray peak intensity	6
4.4.10	Method for measurement of background intensity	6
4.5	Correction method based on analytical models	6
4.5.1	Principles	6
4.5.2	Correction models	7
4.6	Calibration curve method	7
4.6.1	Principle	7
4.6.2	Selection of reference materials	8
4.6.3	Procedure	8
4.7	Uncertainty	8
5	Test report	8
Annex A (informative)	Physical effects and correction	10
Annex B (informative)	Outline of various correction techniques	12
Annex C (informative)	Measurement of the k-ratios in case of "chemical effects"	14
Bibliography		15