ISO 22489:2016-10 (E)

Microbeam analysis - Electron probe microanalysis - Quantitative point analysis for bulk specimens using wavelength di spersive X-ray spectroscopy

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Abbreviated terms 1

4 Procedureforquantification 2
4.1 General procedure for quantitative microanalysis 2
4.1.1 Principle and procedure of quantitative microanalysis 2
4.1.2 Coverage of the quantitative analysis 2
4.1.3 Selection of reference materials 3
4.2 Specimen preparation 3
4.3 Calibration of the instrument 3
4.3.1 Accelerating voltage 3
4.3.2 Probe current 3
4.3.3 X-ray spectrometer 3
4.3.4 Dead time 4
4.4 Analysis conditions 4
4.4.1 Accelerating voltage 4
4.4.2 Probe current 4
4.4.3 Analysis position 4
4.4.4 Probe diameter 5
4.4.5 Scanning the focused electron beam 5
4.4.6 Specimen surface 5
4.4.7 Selection of X-ray line 5
4.4.8 Spectrometer 5
4.4.9 Method for measurement of X-ray peak intensity 6
4.4.10 Method for measurement of background intensity 6
4.5 Correction method based on analytical models 6
4.5.1 Principles 6
4.5.2 Correction models 7
4.6 Calibration curve method 7
4.6.1 Principle 7
4.6.2 Selection of reference materials 8
4.6.3 Procedure 8
4.7 Uncertainty 8

5 Test report 8

Annex A (informative) Physical effects and correction 10

Annex B (informative) Outline of various correction techniques 12

Annex C (informative) Measurement of the k-ratios in case of "chemical effects" 14

Bibliography 15