

ISO 7870-4:2011-07 (E)

Control charts - Part 4: Cumulative sum charts

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions, abbreviated terms and symbols	1
3.1	Terms and definitions	1
3.2	Abbreviated terms	2
3.3	Symbols	3
4	Principal features of cumulative sum (cusum) charts	4
5	Basic steps in the construction of cusum charts -- Graphical representation	5
6	Example of a cusum plot -- Motor voltages	5
6.1	The process	5
6.2	Simple plot of results	6
6.3	Standard control chart for individual results	7
6.4	Cusum chart -- Overall perspective	7
6.5	Cusum chart construction	8
6.6	Cusum chart interpretation	9
6.7	Manhattan diagram	12
7	Fundamentals of making cusum-based decisions	12
7.1	The need for decision rules	12
7.2	The basis for making decisions	13
7.3	Measuring the effectiveness of a decision rule	14
8	Types of cusum decision schemes	16
8.1	V-mask types	16
8.2	Truncated V-mask	16
8.3	Alternative design approaches	22
8.4	Semi-parabolic V-mask	23
8.5	Snub-nosed V-mask	24
8.6	Full V-mask	24
8.7	Fast initial response (FIR) cusum	25
8.8	Tabular cusum	25
9	Cusum methods for process and quality control	27
9.1	The nature of the changes to be detected	27
9.2	Selecting target values	28
9.3	Cusum schemes for monitoring location	29
9.4	Cusum schemes for monitoring variation	39
9.5	Special situations	47
9.6	Cusum schemes for discrete data	49
Annex A (informative)	Von Neumann method	56
Annex B (informative)	Example of tabular cusum	57

Annex C (informative) Estimation of the change point when a step change occurs	61
Bibliography	63