

# DIN EN ISO 11812:2025-04 (E)

Small craft - Watertight or quick-draining recesses and cockpits (ISO 11812:2020 + Amd 1:2024) (includes Amendment :2024)

---

Contents	Page
European foreword	3
<b>A1</b> European foreword to Amendment 1 <b>A1</b>	4
<b>Annex ZA</b> (informative) <b>Relationship between this European Standard and the essential requirements of Directive 2013/53/EU aimed to be covered</b>	5
Foreword	7
<b>A1</b> Foreword to Amendment 1 <b>A1</b>	8
<b>1</b> Scope	9
<b>2</b> Normative references	9
<b>3</b> Terms and definitions	9
<b>4</b> Symbols	14
<b>5</b> General	14
5.1 Loading and measurement conditions	14
5.2 Requirements for watertight and quick-draining recesses	14
<b>6</b> Watertightness requirements	15
6.1 Watertightness requirements for watertight recesses	15
6.2 Watertightness requirements for quick-draining recesses	15
<b>7</b> Requirements for companionway sills	15
7.1 Companionway sills	15
7.2 Quick-draining recess with a reduced risk of flooding	16
7.3 Sill height measurement	16
7.4 Minimum companionway sill height for quick-draining recesses	16
<b>8</b> Height of recess bottom above waterline for quick-draining recesses	17
<b>9</b> Quick-draining recesses — Single bottom recess drainage	17
9.1 Drainage general requirements	17
9.2 Drain requirements	17
9.2.1 Number and dimensions	17
9.2.2 Special provisions	18
9.2.3 Installation	18
9.3 Drainage calculation requirements	19
9.3.1 Drainage calculation principle and assessment methods	19
9.3.2 Simplified drainage assessment method	20
<b>10</b> Quick-draining recesses — Multi-bottom recess drainage	20
10.1 Drainage general requirements	20
10.2 Drainage calculations	21
<b>A1</b> 10.2.1 Drainage calculation requirements <b>A1</b>	21
<b>A1</b> 10.2.2 Example of draining calculation application <b>A1</b>	21
10.3 Drainage requirements for a foot basin	21
<b>A1</b> 10.3.1 General requirements for a foot basin <b>A1</b>	21
<b>A1</b> 10.3.2 Drainage requirements for a foot basin <b>A1</b>	22
<b>11</b> Owner's manual	23
11.1 General recommendation for use	23
11.2 Recommendation for use from <a href="#">Table 4</a> — Companionway opening	23

**Annex A (normative) Full calculation method for draining time .....24**  
**Annex B <sup>A1</sup> (normative) <sup>A1</sup> Technical background — Source of the calculations used .....32**  
**Annex C (informative) Examples of “quick-draining” recesses .....38**  
**<sup>A1</sup> Annex D (informative) Main changes between this document and the first edition <sup>A1</sup> .....40**  
**Bibliography .....41**