

ISO 11812:2020 (E)

Small craft — Watertight or quick-draining recesses and cockpits

Contents

| | |
|---------|---|
| | Foreword |
| 1 | Scope |
| 2 | Normative references |
| 3 | Terms and definitions |
| 4 | Symbols |
| 5 | General |
| 5.1 | Loading and measurement conditions |
| 5.2 | Requirements for watertight and quick-draining recesses |
| 6 | Watertightness requirements |
| 6.1 | Watertightness requirements for watertight recesses |
| 6.2 | Watertightness requirements for quick-draining recesses |
| 7 | Requirements for companionway sills |
| 7.1 | Companionway sills |
| 7.2 | Quick-draining recess with a reduced risk of flooding |
| 7.3 | Sill height measurement |
| 7.4 | Minimum companionway sill height for quick-draining recesses |
| 8 | Height of recess bottom above waterline for quick-draining recesses |
| 9 | Quick-draining recesses — Single bottom recess drainage |
| 9.1 | Drainage general requirements |
| 9.2 | Drain requirements |
| 9.2.1 | Number and dimensions |
| 9.2.2 | Special provisions |
| 9.2.3 | Installation |
| 9.3 | Drainage calculation requirements |
| 9.3.1 | Drainage calculation principle and assessment methods |
| 9.3.2 | Simplified drainage assessment method |
| 10 | Quick-draining recesses — Multi-bottom recess drainage |
| 10.1 | Drainage general requirements |
| 10.2 | Drainage calculations |
| 10.3 | Drainage requirements for a foot basin |
| 11 | Owner's manual |
| 11.1 | General recommendation for use |
| 11.2 | Recommendation for use from Table 4 — Companionway opening |
| Annex A | (normative) Full calculation method for draining time |
| A.1 | Preliminary |
| A.2 | Calculation of a single-bottom recess |
| A.3 | Calculation for a multi-bottom recess |
| A.4 | Principle of calculation where the drain diameters are different |
| A.5 | Determination of minor head loss coefficients, K |
| A.5.1 | General |
| A.5.2 | K coefficient for grid of holes and gratings |
| A.5.3 | K coefficient for drains |

Annex B (informative) Technical background — Source of the calculations used

- B.1 Calculations for a single-bottom recess**
 - B.1.1 General**
 - B.1.2 Calculation for a "perfect" fluid, i.e. no viscosity and no head loss**
- B.2 Calculation with "real" fluids and head losses — General**
- B.3 Calculation of the draining time of a two bottoms recess with "real" fluids and head losses**
 - B.3.1 General**
 - B.3.2 Major (frictional) head losses — For information only**
 - B.3.3 Minor head losses**
- B.4 Water flow in a foot basin**

Annex C (informative) Examples of "quick-draining" recesses

Page count: 32