ISO/IEC 29341-6-17:2008-11 (E)

Information technology_- UPnP Device Architecture_- Part_6-17: Heating, Ventilation, and Air Conditioning Device Control Protocol_- User Operating Mode Service

CONTENTS

FOREWORD 3

ORIGINAL UPNP DOCUMENTS (informative) 5

1. Overview and Scope 7

2. Service Modeling Definitions 8

2.1. ServiceType 8

2.2. State Variables 8

2.2.1. ModeTarget 9
2.2.2. ModeStatus 9
2.2.3. Name 9
2.2.4. Relationships Between State Variables 9

2.3. Eventing and Moderation 10

2.3.1. Event Model 10

2.4. Actions 10

2.4.1. SetModeTarget 11
2.4.2. GetModeTarget 11
2.4.3. GetModeStatus 12
2.4.4. GetName 12
2.4.5. SetName 13
2.4.6. Non-Standard Actions Implemented by a UPnP Vendor 13
2.4.7. Relationships Between Actions 13
2.4.8. Common Error Codes 14

2.5. Theory of Operation 14

3. XML Service Description 15

4. Test 17

LIST OF TABLES

Table 1 State Variables 8

Table 2 AllowedValueList for ModeTarget 8

Table 3 AllowedValueList for ModeStatus 9

Table 4 Eventing & Moderation 10

Table 5 Event Model 10

Table 6 Action list 10

Table 7 Arguments for SetModeTarget 11

Table 8 Arguments for GetModeTarget 11

Table 9 Arguments for GetModeStatus 12

Table 10 Arguments for GetName 12

Table 11 Arguments for SetName 13

Table 12: Common Error Codes 14