

ISO/IEC 9318-4:2002-12 (E)

Information technology - Intelligent peripheral interface - Part 4: Device generic command set for magnetic tape drives (IPI-3_tape)

CONTENTS

- FOREWORD 8
- INTRODUCTION 9
- 1 Scope 10
- 2 Normative references 11
- 3 Definitions and conventions 11
 - 3.1 Definitions 11
 - 3.2 Conventions 13
- 4 Logical interface characteristics of the tape 13
 - 4.1 PhysicalBlocks 13
 - 4.2 DataBlocks 14
 - 4.3 Extents 14
 - 4.4 Partitions 14
 - 4.5 Alternate data areas 15
 - 4.6 Partition parameters 15
 - 4.7 Block numbering 15
 - 4.8 Data buffer operation 15
 - 4.9 Positioning 16
 - 4.9.0 General 16
 - 4.9.1 Mount or rewind 16
 - 4.9.2 Partition transition 16
 - 4.9.3 Normal data operation completion 16
 - 4.9.4 Abnormal data operation completion 17
 - 4.9.5 Normal position operation completion 17
 - 4.9.6 Abnormal position operation completion 17
 - 4.9.7 Tape mark detected 17
 - 4.9.8 BOM detected (reverse operations) 17
 - 4.9.9 EMW detected 17
 - 4.9.10 PEOM detected 17
 - 4.10 Attributes usage 17
 - 4.11 Command usage 18
- 5 Message packet structure 18
- 6 Control commands 18
 - 6.0 General 18
 - 6.1 NOP 18
 - 6.2 FACILITY OPERATION 18
 - 6.3 ATTRIBUTES 18
 - 6.3.1 Command packet 18
 - 6.3.2 Response packet 19
 - 6.3.3 Description 19
 - 6.3.4 Parameters 21
 - 6.4 REPORT ADDRESSEE STATUS 32
 - 6.4.1 Command packet 32
 - 6.4.2 Response packet 32
 - 6.4.3 Description 32

6.4.4	Parameters 50 to 53	32
6.5	PORT ADDRESS.....	33
6.6	PATH CONTROL.....	33
6.7	ATTENTION CONTROL.....	33
6.8	OPERATING MODE	34
6.8.1	Command packet.....	34
6.8.2	Response packet	34
6.8.3	Description	34
6.8.4	Parameters 3E, 50, 53, 54	34
6.9	ABORT.....	37
6.10	ACCESS PERMITS.....	37
6.11	RESUME	37
6.12	PORT RESPONSE	38
6.13	ANTICIPATED ACTION	38
6.14	OPERATOR DISPLAY	38
7	Position commands.....	38
7.0	General	38
7.1	SPACE BLOCK/FILE MARK.....	38
7.1.1	Command packet.....	38
7.1.2	Response packet	38
7.1.3	Description	38
7.1.4	Parameters 31, 32, 35	40
7.2	POSITION CONTROL.....	40
7.2.1	Command packet.....	40
7.2.2	Response packet	40
7.2.3	Description	41
7.2.4	Parameters 31, 32, 35, 3A, 3E, 51, 52, 53, 54, 55.....	41
7.3	REPORT POSITION	46
7.3.1	Command packet.....	46
7.3.2	Response packet	46
7.3.3	Description	46
7.3.4	Parameters 32, 35, 3A, 3E, 51-52	47
7.4	RECORD POSITION.....	48
7.4.1	Command packet.....	48
7.4.2	Response packet	48
7.4.3	Description	48
7.4.4	Parameters 31, 32, 35, 51.....	49
7.5	Reserved	50
8	Transfer commands	50
8.0	General	50
8.1	READ	50
8.1.1	Command packet.....	50
8.1.2	Response packet	50
8.1.3	Description	50
8.1.4	Parameters 31 to 32, 3A, 35, 3E, 51, 52	51
8.2	READ RAW DATA	53
8.2.1	Command packet.....	53
8.2.2	Response packet	53
8.2.3	Description	53

8.2.4	Parameters 31, 32, 35, 3A, 3C, 3E.....	53
8.3	Reserved.....	54
8.4	SEARCH.....	54
8.5	WRITE.....	54
8.5.1	Command packet.....	54
8.5.2	Response packet.....	55
8.5.3	Description.....	55
8.5.4	Parameters 31, 32, 35, 3A, 3C, 3E, 51, 52.....	55
8.6	WRITE PATTERN.....	56
8.7	Reserved.....	56
9	Combination commands.....	56
9.1	COPY.....	56
9.2	COMPARE SLAVE DATA.....	56
9.3	COMPARE DATA.....	56
9.4	Reserved.....	56
9.5	Reserved.....	57
9.6	SHADOW READ.....	57
9.7	SHADOW WRITE.....	57
9.8	SHADOW RESTORE.....	57
10	Other transfer commands.....	57
10.0	General.....	57
10.1	READ VERIFY.....	57
10.1.1	Command packet.....	57
10.1.2	Response packet.....	57
10.1.3	Description.....	57
10.1.4	Parameters 31, 32, 35, 3A, 3C, 3E.....	58
10.2	Reserved.....	59
10.3	READ FROM BUFFER.....	59
10.3.1	Command packet.....	59
10.3.2	Response packet.....	59
10.3.3	Description.....	59
10.3.4	Parameters 31, 32, 35, 3A, 3E, 50.....	61
10.4	READ FACILITY DATA TO BUFFER.....	61
10.5	READ PHYSICAL DATA AND ECC.....	61
10.6	READ PHYSICAL HEADER.....	62
10.7	READ IPL.....	62
10.7.1	Command packet.....	62
10.7.2	Response packet.....	62
10.7.3	Description.....	62
10.8	READ PHYSICAL HEADER AND ECC.....	62
10.9	WRITE TO BUFFER.....	62
10.10	WRITE BUFFER TO FACILITY.....	62
10.11	WRITE PHYSICAL DATA AND ECC.....	62
10.12	WRITE PHYSICAL HEADER.....	63
10.13	LOAD SLAVE IML.....	63
10.14	ERASE.....	63
10.14.1	Command packet.....	63
10.14.2	Response packet.....	63
10.14.3	Description.....	63

10.14.4	Parameters 31, 32, 35, 3A, 3E	64
10.15	WRITE PHYSICAL HEADER AND ECC	64
11	Diagnostic commands	64
11.0	General	64
11.1	PERFORM SLAVE DIAGNOSTICS	64
11.2	PERFORM FACILITY DIAGNOSTICS	65
11.3	Reserved	65
11.4	Reserved	65
11.5	READ ERROR LOG	65
11.5.1	Command packet	65
11.5.2	Response packet	65
11.5.3	Description	65
11.6	WRITE ERROR LOG	65
11.7	DIAGNOSTIC CONTROL	65
12	Command summary	66
12.1	Control commands	66
12.2	Position commands	67
12.3	Transfer commands	67
12.4	Combination commands	67
12.5	Other transfer commands	68
12.6	Diagnostic commands	69
Annex A (normative)	Overview: interface levels, concepts and application environments	70
A.1	Interface levels	70
A.2	Concepts	70
A.2.0	General	70
A.2.1	Relationship of master, slave and facility	70
A.2.2	Relationship of facilities and partitions	71
A.2.3	Command structure	71
A.3	Application environments	71
A.3.0	General	71
A.3.1	Control of facilities by the master	72
A.3.2	Shared control of facilities	72
A.3.3	Control of facilities by the slave	72
Figure 1	– Command packet for ATTRIBUTES	18
Figure 2	– Response packet for ATTRIBUTES	19
Figure 3	– Command packet for REPORT ADDRESSEE STATUS	32
Figure 4	– Response packet for REPORT ADDRESSEE STATUS	32
Figure 5	– Command packet for OPERATING MODE	34
Figure 6	– Response packet for OPERATING MODE	34
Figure 7	– Command packet for SPACE BLOCK/FILE MARK	38
Figure 8	– Response packet for SPACE BLOCK/FILE MARK	38
Figure 9	– Command packet for POSITION CONTROL	40
Figure 10	– Response packet for POSITION CONTROL	40
Figure 11	– Command packet for REPORT POSITION	46
Figure 12	– Response packet for REPORT POSITION	46

Figure 13 – Command packet for RECORD POSITION	48
Figure 14 – Response packet for RECORD POSITION.....	48
Figure 15 – Command packet for READ	50
Figure 16 – Response packet for READ	50
Figure 17 – Command packet for READ RAW DATA	53
Figure 18 – Response packet for READ RAW DATA	53
Figure 19 – Command packet for WRITE	54
Figure 20 – Response packet for WRITE.....	55
Figure 21 – Command packet for READ VERIFY.....	57
Figure 22 – Response packet for READ VERIFY	57
Figure 23 – Command packet for READ FROM BUFFER	59
Figure 24 – Response packet for READ FROM BUFFER.....	59
Figure 25 – Command packet for READ IPL.....	62
Figure 26 – Response packet for READ IPL	62
Figure 27 – Command packet for ERASE	63
Figure 28 – Response packet for ERASE	63
Figure 29 – Command packet for READ ERROR LOG.....	65
Figure 30 – Response packet for READ ERROR LOG	65
Table 1 – Attributes parameters 3A, 3E, 50	21
Table 2 – Attributes parameters 51 to 58.....	22
Table 3 – Attributes parameters 59, 5A	23
Table 4 – Attributes parameters 5B to 5D.....	23
Table 5 – Attributes parameters 5E to 65	23
Table 6 – Attributes parameters 66, 67.....	24
Table 7 – Attributes parameter 68	24
Table 8 – Attributes parameters 69, 6A	24
Table 9 – Attributes parameters 6B to 6F	25
Table 10 – Attributes parameters 70, 71.....	25
Table 11 – Attributes parameter 72	27
Table 12 – Attributes parameter 73	28
Table 13 – Attributes parameters 74, 75.....	30
Table 14 – Attributes parameters 76 to 79.....	31
Table 15 – Report addressee status parameters 50 to 53.....	33
Table 16 – Operating mode parameters 3E, 50, 52	35
Table 17 – Operating mode parameter 53	36
Table 18 – Operating mode parameter 54	37
Table 19 – Space block/file mark parameters 31, 32, 35	40
Table 20 – Position control parameters 31 to 32, 35, 3A, 3E, 51 to 53.....	42
Table 21 – Position control parameters 54, 55	43
Table 22 – Report position parameters 32, 35, 3A, 3E, 51, 52.....	47
Table 23 – Record position parameters 31, 32, 35, 3A, 51	49

Table 24 – Read parameters 31, 32, 35, 3A, 3C, 3E, 51, 52.....	52
Table 25 – Read raw data parameters 31, 32, 35, 3A, 3C, 3E	54
Table 26 – Write parameters 31, 32, 35, 3A, 3C, 3E, 51, 52.....	55
Table 27 – Read verify parameters 31, 32, 35, 3A, 3C, 3E	58
Table 28 – Read from buffer parameters 31, 32, 35, 3A, 3E, 50	61
Table 29 – Erase parameters 31, 32, 35, 3A, 3E	64