

# ISO 14404-1:2024-09 (E)

## Calculation method of carbon dioxide emission intensity from iron and steel production - Part 1: Steel plant with blast furnace

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	1
3.1	Emissions .....	1
3.2	Gas fuel .....	2
3.3	Liquid fuel .....	2
3.4	Solid fuel .....	3
3.5	Auxiliary material .....	4
3.6	Energy carriers .....	4
3.7	Ferrous containing materials .....	5
3.8	Alloys .....	5
3.9	Other imported/exported materials .....	6
3.10	Others .....	6
4	Symbols .....	7
5	Principles .....	8
5.1	General .....	8
5.2	Relevance .....	8
5.3	Completeness .....	8
5.4	Consistency .....	8
5.5	Accuracy .....	8
5.6	Transparency .....	8
6	Boundary .....	8
6.1	General .....	8
6.2	Category 1 .....	9
6.3	Category 2 .....	9
6.4	Category 3 .....	10
6.5	Category 4 .....	10
7	Calculation .....	10
7.1	General .....	10
7.2	Calculation procedure .....	10
7.2.1	Data collection of crude steel production .....	10
7.2.2	Data collection direct and/or upstream CO <sub>2</sub> emission sources .....	11
7.2.3	Data collection of credit CO <sub>2</sub> emission sources .....	12
7.2.4	Calculation .....	14
Annex A (informative) Calculation of energy consumption and intensity .....		16
Annex B (informative) Example of template for using different emission factors or emission sources from Table 4 .....		18

<b>Annex C (informative) Example of CO2 emission and intensity calculations for a steel plant -- Data of a steel plant .....</b>	<b>20</b>
<b>Annex D (informative) Explanation of emission factors for by-product gases in Table 4 .....</b>	<b>24</b>
<b>Annex E (informative) Decarbonization strategies and its impact on CO2 calculation method .....</b>	<b>27</b>
<b>Bibliography .....</b>	<b>28</b>