

# ISO 7076-2:2012-05 (E)

## Fire protection - Foam fire extinguishing systems - Part 2: Low expansion foam equipment

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>4</b>	<b>Requirements .....</b>	<b>3</b>
4.1	Connections .....	3
4.2	Parts for removal during routine field maintenance .....	3
4.3	Corrosion resistance of metal parts .....	3
4.4	Elastomeric joint rings .....	3
4.5	Plastics and reinforced resin materials .....	3
4.6	Strength .....	4
4.7	Leak resistance .....	4
4.8	Discharge coefficient (K factor) .....	4
4.9	Foam quality .....	4
4.10	Water flow .....	5
4.11	Range of discharge .....	5
4.12	Vapour seal .....	5
4.13	Operation reliability .....	5
4.14	Stress corrosion .....	5
4.15	Salt-spray corrosion .....	5
4.16	Light and water exposure .....	5
4.17	Heat and fire resistance .....	6
<b>5</b>	<b>Test methods .....</b>	<b>6</b>
5.1	General .....	6
5.2	Ageing test for plastics and reinforced resin materials .....	6
5.3	Liquid exposure test .....	6
5.4	Equipment pressurization test .....	6
5.5	Leak resistance test .....	6
5.6	Flow coefficient measurement .....	6
5.7	Measurement of expansion ratio and drainage time .....	7
5.8	Water flow test .....	7
5.9	Range tests for branchpipe and monitor .....	7
5.10	Vapour sealing test .....	7
5.11	Operation reliability test .....	7
5.12	Stress corrosion test .....	8
5.13	Salt-spray corrosion test .....	8
5.14	Light and water exposure test .....	9
5.15	Heat and fire resistance .....	9
<b>6</b>	<b>Marking .....</b>	<b>9</b>
<b>7</b>	<b>Manufacturer's installation and operation instructions .....</b>	<b>9</b>
<b>Annex A (normative) Tolerances .....</b>		<b>10</b>
<b>Bibliography .....</b>		<b>11</b>