

DIN EN 14825:2012-06 (E)

Air conditioners, liquid chilling pack ages and heat pumps, with electrically driven compressors, for space heating and cooling - Testing and rating at part load conditions and calculation of seasonal performance

Contents		Page
Foreword		4
Introduction		5
1	Scope	6
2	Normative references	6
3	Terms, definitions, symbols, abbreviated terms and units	6
3.1	Terms and definitions	6
3.2	Symbols, abbreviated terms and units	13
4	Part load conditions in cooling mode	15
4.1	General	15
4.2	Air-to-air units	15
4.3	Water-to-air units and brine-to-air units	15
4.4	Air-to-water units	16
4.5	Water-to-water and brine-to-water units	16
5	Part load conditions in heating mode	17
5.1	General	17
5.2	Air-to-air units	18
5.3	Water-to-air and brine-to-air units	19
5.4	Air-to-water units	20
5.4.1	General	20
5.4.2	Low temperature application	21
5.4.3	Medium temperature application	24
5.4.4	High temperature application	26
5.4.5	Very high temperature application	29
5.5	Water-to-water and brine-to-water units	31
5.5.1	General	31
5.5.2	Low temperature application	32
5.5.3	Medium temperature application	35
5.5.4	High temperature application	38
5.5.5	Very high temperature application	41
6	Calculation methods for reference SEER and reference SEERon	43
6.1	General formula for calculation of reference SEER	43
6.2	Calculation of the reference annual cooling demand (Qc)	44
6.3	Calculation of reference SEERon	44
6.4	Calculation procedure for determination of EERPL values at part load conditions B, C, D	45
6.4.1	General	45
6.4.2	For air-to-air & water-to-air units	45
6.4.3	Air-to-water, water-to-water & brine-to-water units	46
7	Calculation methods for reference SCOP, reference SCOPon and reference SCOPnet	47
7.1	General formula for calculation of reference SCOP	47
7.2	Calculation of the reference annual heating demand (Qh)	47
7.3	Calculation of reference SCOPon and reference SCOPnet	48

7.4	Calculation procedure for determination of COPPL values at part load conditions A, B, C, D	50
7.4.1	General	50
7.4.2	For air-to-air, brine-to-air and water-to-air units	50
7.4.3	For air-to-water, water-to-water and brine-to-water units	51
8	Test methods for testing capacities, EERPL and COPPL values during active mode at part load conditions	52
8.1	General	52
8.2	Basic principles	52
8.3	Uncertainties of measurement	53
8.4	Test procedures for units with fixed capacity	54
8.4.1	General	54
8.4.2	Air-to-air and water-to-air units - Determination of the degradation coefficient Cd	54
8.4.3	Air-to-water units and water-to-water units - Determination of the degradation factor Cc ..	55
8.5	Test procedure for variable capacity units (air-to-air, air-to-water, water-to-air, water/brine-to-water)	56
8.5.1	Air-to-air & water-to-air units	56
8.5.2	Air-to-water and water/brine-to-water units	56
9	Test methods for electric power consumption during thermostat off mode, standby mode and crankcase heater mode	56
9.1	Measurement of electric power consumption during thermostat off mode	56
9.2	Measurement of the electric power consumption during standby mode	57
9.3	Measurement of the electric power consumption during crankcase heater mode	57
9.4	Measurement of the electric power consumption during off mode	57
10	Test report	57
11	Technical data sheet	57
Annex A (informative) Calculation example for reference SEER_{on} and reference SEER - Application of an air-to-air unit with variable capacity		58
A.1	Calculation of SEER _{on}	58
A.2	Calculation of SEER	59
A.2.1	Calculation of reference annual cooling demand (Q _c) according to Equation (2)	59
A.2.2	Calculation of reference SEER according to Equation (1)	59
Annex B (informative) Calculation example for reference SCOP_{on} and reference SCOP_{net} of a fixed capacity air-to-water heat pump used for floor heating		60
Annex C (informative) Adaption of water temperature for fixed capacity units		64
Annex D (informative) Determination of reference annual cooling/heating demands and determination of hours for active mode, thermostat off, standby, off mode and crankcase heater mode		67
D.1	General track	67
D.2	Determination of reference annual cooling/heating demands and hours for active mode, thermostat off, standby, off mode	67
D.3	Hours used for crankcase heater mode	69
Annex E (informative) Compensation method for air-to-water and water/brine-to-water units		70
E.1	General	70
E.2	Compensation system for reduced capacity test in cooling mode	70
E.3	Compensation system for reduced capacity test in heating mode	71
Bibliography		72