DIN EN 378-4:2008-06 (E)

Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, rep air and recovery

Contents

Page

Foreword 3

1 Scope 4

2 Normative references 4

3 Terms and definitions 4

4 General requirements 5
4.1 Operational instructions 5
4.2 Instruction of operating personnel 5
4.3 Documentation 5

5 Maintenance and repair 6
5.1 General 6
5.2 Maintenance 6
5.3 Repair 7
5.4 Change of refrigerant type 8

6 Requirements for recovery, reuse and disposal 9
6.1 General requirements 9
6.2 Requirements for recovery and reuse of refrigerant 10
6.3 Requirements for refrigerant transfer, transport and storage 13
6.4 Requirements for recovery equipment 14
6.5 Requirements for disposal 15
6.6 Requirements for documentation 15

Annex A (normative) Draining the oil from a refrigerating system 16

Annex B (informative) Guide specification (parameters) for recycled refrigerant 17

Annex C (informative) Handling and storage of refrigerants 18

Annex D (informative) In-service inspection 20

Annex E (informative) Guidelines for repairs of equipment using flammable refrigerants 22

Bibliography 25