

DIN EN 13231-1:2013-07 (E)

Railway applications - Track - Acceptance of works - Part 1: Works on ballasted track - Plain line, switches and crossings

Contents		Page
Foreword		3
1	Scope	4
2	Normative references	4
3	Terms and definitions	4
4	Acceptance of works on plain line and on switches and crossings and rail expansion devices	6
4.1	General	6
4.2	Acceptance deadlines	6
4.3	Acceptance measurements, checks and related documentation	7
4.4	Relative track geometry	8
4.5	Absolute track position	11
4.6	Other parameters and verifications for plain line and switches and crossings	12
4.7	Specific measurements for switches and crossings and rail expansion devices	15
4.8	Specific quality checks for switches and crossings and rail expansion devices	16
5	Working parameters	17
5.1	General	17
5.2	Tamping working parameters	17
5.3	Dynamic stabilising working parameters	18
5.4	Ballast compaction working parameters	19
5.5	Ballast replacement/cleaning working parameters	19
6	Acceptance responsibilities	20
6.1	Preliminary procedure to acceptance	20
6.2	Consequences of the preliminary procedure to the acceptance	21
7	Warranty	21
Annex A (informative) Guidelines for specification of requirements of geodetic measurements		22
Annex B (informative) Switches and crossings measurements and checks		23
Bibliography		30