

DIN EN 16019:2014-06 (E)

Railway applications - Automatic coupler - Performance requirements, specific interface geometry and test method

| Contents | Page |
|--|-------------|
| Foreword | 4 |
| 1 Scope | 5 |
| 2 Normative references | 5 |
| 3 Terms and definitions | 5 |
| 4 Product requirements | 6 |
| 4.1 Automatic coupler head characteristics | 6 |
| 4.2 Coupling system positions | 8 |
| 4.2.1 General | 8 |
| 4.2.2 Ready-to-couple position | 8 |
| 4.2.3 Coupled position | 8 |
| 4.2.4 Uncoupled position | 9 |
| 4.3 Coupling requirements | 9 |
| 4.3.1 Mechanical coupling | 9 |
| 4.3.2 Pneumatic coupling | 10 |
| 4.4 Uncoupling | 11 |
| 5 Tests | 11 |
| 5.1 Type tests | 11 |
| 5.1.1 General | 11 |
| 5.1.2 Strength test | 11 |
| 5.1.3 Dimension test | 14 |
| 5.1.4 Gathering range test | 15 |
| 5.2 Routine tests | 15 |
| 5.2.1 General | 15 |
| 5.2.2 Visual checks | 15 |
| 5.2.3 Dimension test | 15 |
| 5.2.4 Function tests | 15 |
| Annex A (normative) Automatic coupler interface | 17 |
| Annex B (informative) Gathering range | 22 |
| Annex C (informative) Example method of coupler lock play measurement | 23 |
| Annex D (normative) Air pipe connections | 26 |
| Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2008/57/EC | 28 |
| Bibliography | 30 |
| Figures Page Figure 1 -- Principle arrangement of coupler head | 7 |
| Figure 2 -- Ready-to-couple position | 8 |
| Figure 3 -- Coupled position | 9 |

| | |
|---|-----------|
| Figure 4 -- Uncoupled position | 9 |
| Figure 5 -- Successful coupling in curves | 10 |
| Figure 6 -- Unsuccessful coupling in curves | 10 |
| Figure 7 -- Strain gauges on the coupler head housing for the tensile test (tensile and compressive) | 12 |
| Figure 8 -- Strain gauge on the hook plate for the tensile test | 13 |
| Figure 9 -- Strain gauges on the coupling link for the tensile test | 13 |
| Figure A.1 -- Automatic coupler head (front view) | 17 |
| Figure A.2 -- Automatic coupler head (top view) | 18 |
| Figure A.3 -- Automatic coupler head (lateral view) | 19 |
| Figure A.4 -- Automatic coupler head in the coupled position (cross section) | 20 |
| Figure A.5 -- Automatic coupler head (isometric view) | 21 |
| Figure B.1 -- Typical gathering range of the Type 10 coupler | 22 |
| Figure B.2 -- Typical gathering range of the Type 10 coupler with guide bar | 22 |
| Figure C.1 -- Coupler lock play gauge Type 10 | 23 |
| Figure C.2 -- Coupler lock play gauge | 24 |
| Figure C.3 -- Coupler lock play measurement | 25 |
| Figure D.1 -- Brake pipe valve | 26 |
| Figure D.2 -- Main reservoir and uncoupling valve | 27 |