

DIN EN 14750:2025-02 (E)

Railway applications - Air conditioning for urban, suburban and regional rolling stock - Comfort parameters and type tests

Contents		Page
	European foreword	5
1	Scope.....	6
2	Normative references.....	6
3	Terms and definitions.....	6
4	Parameter selection.....	13
5	Vehicle categories.....	13
6	Comfort parameters.....	15
7	Exterior conditions.....	16
7.1	Generalities.....	16
7.2	Mean exterior temperature range with comfort criteria	16
7.3	Mean exterior temperature range with functional criteria	17
8	Performance of the heating and cooling installations.....	17
8.1	Design passenger load	17
8.2	Heating.....	17
8.3	Pre-heating.....	17
8.4	Cooling	18
8.5	Pre-cooling	18
8.6	Stand by operation	18
9	Control	19
9.1	General.....	19
9.2	Interior temperature setpoint (T_{ic}).....	19
9.3	Interior temperature setpoint (T_{ic}) for vehicles without cooling	19
10	Comfort condition requirements	19
10.1	Requirements for comfort zone.....	19
10.2	Requirements for local annexes (T_{Loc})	29
10.3	Air quantities and quality	30
11	Complementary requirements	30
11.1	Heat transfer coefficient (k).....	30
11.2	Condensation.....	31
11.3	Solar factor (g) of the windows.....	31
11.4	Sealing against water and snow	31
12	Validation	31
12.1	General.....	31
12.2	Test levels	31
12.3	Selection of tested vehicles	32
12.4	Assessment of comfort criteria based on simulation	32
13	Preliminary verifications.....	34
14	Air movement tests	34
14.1	General remarks	34
14.2	Air flow rates	34
14.3	Visualization of the air flow direction.....	34

14.4	Air speed test.....	35
15	Climatic tests	35
15.1	General remarks	35
15.2	Pre-heating test.....	36
15.3	Pre-cooling test.....	36
15.4	Regulation test.....	36
15.5	Steady-state tests.....	37
15.6	Tests at extreme exterior operating conditions.....	38
15.7	Complementary tests	38
16	Methods of measurement – Measuring instruments.....	41
16.1	General remarks	41
16.2	Temperatures	41
16.3	Relative humidity	41
16.4	Air speed	42
16.5	Air flow rate.....	42
16.6	Simulated speed of the vehicle	42
16.7	Equivalent solar energy	42
16.8	Energy consumption and power rating.....	42
17	Characteristics of the test equipment	42
17.1	General remarks	42
17.2	Occupation	42
17.3	Temperature and uniformity of the climatic chamber and climatic wind tunnel	43
17.4	Relative exterior humidity.....	43
17.5	Simulation of exterior air speed	43
17.6	Equivalent solar energy	43
18	Distribution of measuring points	46
18.1	General	46
18.2	Comfort envelope temperature measuring points.....	46
	Annex A (normative) Form for parameters selection	47
	Annex B (normative) Regulation curves for the interior temperature setpoint.....	51
	Annex C (normative) Acceptable air speed	53
	Annex D (normative) Maximum Relative interior humidity in the comfort envelope	55
	Annex E (normative) Heat emitted by a person.....	57
	Annex F (normative) Exterior conditions for climatic zones.....	60
	Annex G (normative) Fresh air flow.....	62
	Annex H (normative) Test programme for TL1	64
	Annex I (normative) Test programme for TL2 and TL3	66
	Annex J (normative) Equivalent solar energy (Simulation of solar exposure)	75
	Annex K (normative) Location of the measuring points used for the determination of the mean interior temperature in the comfort envelope (T_{im}), horizontal (ΔT_H) and vertical (ΔT_V) range of the extreme interior air temperatures, floor surface temperature (T_{S_FI}), relative interior humidity (RH_{im}), interior CO ₂ concentration (C_{im}) in the comfort envelopes and local annexes.....	76
	Annex L (normative) Location of the measuring points used for the determination of surface temperatures	81
	Annex M (normative) Location of other sensors.....	84
	Annex N (informative) Coefficient k	88
	Annex O (normative) Calculation method of the comfort level CL.....	89

Annex P (informative) Simulation	102
Annex Q (normative) Set-up of the simulation.....	108
Annex R (informative) Abbreviations	114
Bibliography	117