DIN EN 14750:2025-02 (E)

Railway applications - Air conditioning for urban, suburban and regional rolling stock - Comfort parameters and type tests

Contents

Page

European foreword 5

1 Scope 6

2 Normative references 6

3 Terms and definitions 6

4 Parameter selection 13

5 Vehicle categories 13

6 Comfort parameters 15

7 Exterior conditions 16
7.1 Generalities 16
7.2 Mean exterior temperature range with comfort criteria 16
7.3 Mean exterior temperature range with functional criteria 17

8 Performance of the heating and cooling installations 17
8.1 Design passenger load 17
8.2 Heating 17
8.3 Pre-heating 17
8.4 Cooling 18
8.5 Pre-cooling 18
8.6 Stand by operation 18

9 Control 19
9.1 General 19
9.2 Interior temperature setpoint (T_{ic}) 19
9.3 Interior temperature setpoint (T_{ic}) for vehicles without cooling 19

10 Comfort condition requirements 19
10.1 Requirements for comfort zone 19
10.2 Requirements for local annexes (T_{Loc}) 29
10.3 Air quantities and quality 30

11 Complementary requirements 30
11.1 Heat transfer coefficient (k) 30
11.2 Condensation 31
11.3 Solar factor (g) of the windows 31
11.4 Sealing against water and snow 31

12 Validation 31
12.1 General 31
12.2 Test levels 31
12.3 Selection of tested vehicles 32
12.4 Assessment of comfort criteria based on simulation 32

13 Preliminary verifications 34

14 Air movement tests 34
14.1 General remarks 34
14.2 Air flow rates 34
14.3 Visualization of the air flow direction 34

14.4 Air speed test 35
15 Climatic tests 35
15.1 General remarks 35
15.2 Pre-heating test 36
15.3 Pre-cooling test 36
15.4 Regulation test 36
15.5 Steady-state tests 37
15.6 Tests at extreme exterior operating conditions 38
15.7 Complementary tests 38
16 Methods of measurement – Measuring instruments 41
16.1 General remarks 41
16.2 Temperatures 41
16.3 Relative humidity 41
16.4 Air speed 42
16.5 Air flow rate 42
16.6 Simulated speed of the vehicle 42
16.7 Equivalent solar energy 42
16.8 Energy consumption and power rating 42
17 Characteristics of the test equipment 42
17.1 General remarks 42
17.2 Occupation 42
17.3 Temperature and uniformity of the climatic chamber and climatic wind tunnel 43
17.4 Relative exterior humidity 43
17.5 Simulation of exterior air speed 43
17.6 Equivalent solar energy 43
18 Distribution of measuring points 46
18.1 General 46
18.2 Comfort envelope temperature measuring points 46
Annex A (normative) Form for parameters selection 47
Annex B (normative) Regulation curves for the interior temperature setpoint 51
Annex C (normative) Acceptable air speed 53
Annex D (normative) Maximum Relative interior humidity in the comfort envelope 55
Annex E (normative) Heat emitted by a person 57
Annex F (normative) Exterior conditions for climatic zones 60
Annex G (normative) Fresh air flow 62
Annex H (normative) Test programme for TL1 64
Annex I (normative) Test programme for TL2 and TL3 66
Annex J (normative) Equivalent solar energy (Simulation of solar exposure) 75
Annex K (normative) Location of the measuring points used for the determination of the mean interior temperature in the comfort envelope (T_{im}), horizontal (ΔT_H) and vertical (ΔT_V) range of the extreme interior air temperatures, floor surface temperature (T_{S_Fl}), relative interior humidity (RH_{im}), interior CO_2 concentration (C_{im}) in the comfort envelopes and local annexes 76
Annex L (normative) Location of the measuring points used for the determination of surface temperatures 81
Annex M (normative) Location of other sensors 84
Annex N (informative) Coefficient k 88
Annex O (normative) Calculation method of the comfort level CL 89

Annex P (informative) Simulation 102
Annex Q (normative) Set-up of the simulation 108
Annex R (informative) Abbreviations 114
Bibliography 117